



FCAR F3 Diagnosis list

Automaker:	BENZ diesel
Software Version:	V6.7

Model	Model	System	System	Function					
				Version info.	Readout DTC	Clear DTC	Read Data stream	Action test	Remark(other functions)
		ACTROS WDB930.0 - 934.0(16 pin socket)	GM-Basic module	√	√	√	√	-	-
			MR- engine control	√	√	√	√	-	-
			INS-Dashboard	√	√	√	√	-	-
			BS-Brake control	√	√	√	√	-	-
			ZHE-Assit heater	√	√	√	√	-	-
			FM-Front module	√	√	√	√	-	-
			MSF-Switch panel	√	√	√	√	-	-
			MTCO-Conversion Tab	√	√	√	√	-	-
			GS-Gear Shift control	√	√	√	√	-	-
			FR-Drive control	√	√	√	√	-	-
			HM-Rear module	√	√	√	√	-	-
			TMF-Driver Door Module	√	√	√	-	-	-
			ABA-Active Brake Assist	√	√	√	√	-	-
			DTCO-digital tachograph	√	√	√	√	-	-
			EHZ electro-hydraulic auxiliary steering	√	√	√	√	-	-
			BNT navigation or telephone operating unit	√	√	√	√	-	-
			BTS battery disconnect switch	√	√	√	√	-	-
			HPS hydraulic pneumatic shift	√	√	√	√	-	-
			PSM Parameterizable Special Module	√	√	√	√	-	-

BENZ Diesel	ACTROS	RDK tire pressure control	✓	✓	✓	✓	-	-
		SPA Lane Assistant	✓	✓	✓	✓	✓	-
		Steering wheel angle sensor	✓	✓	✓	✓	-	-
		WS Maintenance System	✓	✓	✓	✓	-	-
		WSK torque converter clutch or TK turbo clutch	✓	✓	✓	✓	-	-
		ZDS Central data memory	✓	✓	✓	✓	-	-
		FLA flame starting system	✓	✓	✓	✓	-	-
		GM-Basic module	✓	✓	✓	✓	-	-
		MR- engine control	✓	✓	✓	✓	-	-
		INS-Dashboard	✓	✓	✓	✓	-	-
		BS-Brake control	✓	✓	✓	✓	-	-
		ZHE-Assit heater	✓	✓	✓	✓	-	-
		FM-Front module	✓	✓	✓	✓	-	-
		MSF-Switch panel	✓	✓	✓	✓	-	-
		MTCO-Conversion Tab	✓	✓	✓	✓	-	-
		GS-Gear Shift control	✓	✓	✓	✓	-	-
		FR-Drive control	✓	✓	✓	✓	-	-
		HM-Rear module	✓	✓	✓	✓	-	-
		TMF-Driver Door Module	✓	✓	✓	-	-	-
		ABA-Active Brake Assist	✓	✓	✓	✓	-	-
		DTCO-digital tachograph	✓	✓	✓	✓	-	-
		EHZ electro-hydraulic auxiliary steering	✓	✓	✓	✓	-	-
		BNT navigation or telephone operating unit	✓	✓	✓	✓	-	-

	ACTROS WDB950.0 - 954.0(14 pin socket)	BTS battery disconnect switch	✓	✓	✓	✓	—	-
		HPS hydraulic pneumatic shift	✓	✓	✓	✓	—	-
		PSM Parameterizable Special Module	✓	✓	✓	✓	—	-
		RDK tire pressure control	✓	✓	✓	✓	—	-
		SPA Lane Assistant	✓	✓	✓	✓	✓	-
		Steering wheel angle sensor	✓	✓	✓	✓	—	-
		WS Maintenance System	✓	✓	✓	✓	—	-
		WSK torque converter clutch or TK turbo clutch	✓	✓	✓	✓	—	-
		ZDS Central data memory	✓	✓	✓	✓	—	-
		FLA flame starting system	✓	✓	✓	✓	—	-
ACTROS MP II	ACTROS MP II WDB930.0 - 934.0(16 pin socket)	VDO FR-Drive control vehicle-engineECU	✓	✓	✓	—	—	-
		FM-Front module	✓	✓	✓	✓	—	-
		HM-Rear module	✓	✓	✓	✓	—	-
	ACTROS MP II WDB950.0 - 954.0(14 pin socket)	VDO FR-Drive control vehicle-engineECU	✓	✓	✓	—	—	-
		FM-Front module	✓	✓	✓	✓	—	-
		HM-Rear module	✓	✓	✓	✓	—	-
		MR engine control	✓	✓	✓	✓	✓	-
		PSM Parameterizable Special Module	✓	✓	✓	✓	—	-
		NR level control	✓	✓	✓	✓	✓	-

	Atego	ATEGO WDB970 - 976, NAB374.4	INS Instrument	✓	✓	✓	✓	–	-
			FR drive control	✓	✓	✓	✓	✓	-
			ABS anti-lock braking system	✓	✓	✓	✓	✓	-
			FFB radio remote control	✓	✓	✓	✓	✓	-
			HPS hydraulic pneumatic shift	✓	✓	✓	✓	–	-
			ZV central locking system	✓	✓	✓	✓	–	-
			ANG Automatic transmission commercial vehicle	✓	✓	✓	✓	–	-
			SRS supplemental restraint system	✓	✓	✓	✓	–	-
	ECONIC	ECONIC 957.5 - 957.6	MR engine control	✓	✓	✓	✓	–	-
			PSM Parameterizable Special Module	✓	✓	✓	✓	–	-
			NR level control	✓	✓	✓	✓	✓	-
			INS Instrument	✓	✓	✓	✓	–	-
			FR drive control	✓	✓	✓	✓	✓	-
			ABS anti-lock braking system	✓	✓	✓	✓	✓	-
			WS Maintenance System	✓	✓	✓	✓	–	-
Vario 512	Vario 512 WDB930.0 - 934.0(16 pin socket)	ABS Bosch 5.3	✓		✓	–	–	-	
		Bosch MR PF Pump(PLD/PLN injection system)	✓	✓	✓	–	–	-	
Remarks: ✓ means the system has this function - means not supported at this moment.									