

Mark X Description Function is supported.

Special Function

Automaker	Region	Year	Model	Vehicle Type	ECU Type	System	ECU Supplier	Sys. Info.	Read Code	Clear Code	Data Stream	Actuation	Special Functions
AUSFORD	Australia	2011	Falcon FG XR6 4.0L			PCM -POWERTRAIN CONTROL MODULE			X	X	X		KOEO On Demand Self-Test KOER On Demand Self-Test Reset KAM
AUSFORD	Australia	2011	Falcon FG XR6 4.0L			TCM -TRANS CONTROL MODULE			X	X	X		KOEO On Demand Self-Test KOER On Demand Self-Test
AUSFORD	Australia	2011	Falcon FG XR6 4.0L			ABS -ANTILOCK BRAKE MODULE			X	X	X		On-Demand Self-Test ABS Service Bleed Steering angle sensor
AUSFORD	Australia	2011	Falcon FG XR6 4.0L			RCM -RESTRAINT CONTROL MODULE			X	X	X		On-Demand Self-Test
AUSFORD	Australia	2011	Falcon FG XR6 4.0L			BEM -BODY ELECTRIC MODULE			X	X	X		On-Demand Self-Test Erase and Program Keys PCM Parameter Reset
AUSFORD	Australia	2011	Falcon FG XR6 4.0L			ICM -INSTRUMENT CLUSTER MODULE			X	X	X		On-Demand Self-Test
AUSFORD	Australia	2011	Falcon FG XR6 4.0L			HIM -HVAC INTEGRATED MODULE			X	X	X		On-Demand Self-Test
AUSFORD	Australia	2011	Falcon FG XR6 4.0L			ACM -AUDIO CONTROL MODULE		X	X	X	X		On-Demand Self-Test
AUSFORD	Australia	2011	Falcon FG XR6 4.0L			AIM -AUDIO INTERFACE MODULE			X	X	X		On-Demand Self-Test
AUSFORD	Australia	2011	Falcon FG XR6 4.0L			FDIM -FRONT DISPLAY INTERFACE MODULE			X	X	X		On-Demand Self-Test
AUSFORD	Australia	2011	Falcon FG XR6 4.0L			BPM -BLUETOOTH PHONE MODULE			X	X	X		On-Demand Self-Test

Mark X Description Function is supported.

AUSFORD	Australia	2011	Falcon G6E 4.0L Turbo FG			PCM -POWERTRAIN CONTROL MODULE			X	X	X		KOEO On Demand Self-Test KOER On Demand Self-Test Reset KAM
AUSFORD	Australia	2011	Falcon G6E 4.0L Turbo FG			TCM -TRANS CONTROL MODULE			X	X	X		KOEO On Demand Self-Test KOER On Demand Self-Test
AUSFORD	Australia	2011	Falcon G6E 4.0L Turbo FG			ABS -ANTILOCK BRAKE MODULE			X	X	X		On-Demand Self-Test ABS Service Bleed Steering angle sensor
AUSFORD	Australia	2011	Falcon G6E 4.0L Turbo FG			RCM -RESTRAINT CONTROL MODULE			X	X	X		On-Demand Self-Test
AUSFORD	Australia	2011	Falcon G6E 4.0L Turbo FG			BEM -BODY ELECTRIC MODULE			X	X	X		On-Demand Self-Test Erase and Program Keys PCM Parameter Reset
AUSFORD	Australia	2011	Falcon G6E 4.0L Turbo FG			ICM -INSTRUMENT CLUSTER MODULE			X	X	X		On-Demand Self-Test
AUSFORD	Australia	2011	Falcon G6E 4.0L Turbo FG			HIM -HVAC INTEGRATED MODULE			X	X	X		On-Demand Self-Test
AUSFORD	Australia	2011	Falcon G6E 4.1L Turbo FG			ACM -AUDIO CONTROL MODULE		X	X	X	X		On-Demand Self-Test
AUSFORD	Australia	2011	Falcon G6E 4.1L Turbo FG			AIM -AUDIO INTERFACE MODULE			X	X	X		On-Demand Self-Test
AUSFORD	Australia	2011	Falcon G6E 4.1L Turbo FG			FDIM -FRONT DISPLAY INTERFACE MODULE			X	X	X		On-Demand Self-Test
AUSFORD	Australia	2011	Falcon G6E 4.1L Turbo FG			BPM -BLUETOOTH PHONE MODULE			X	X	X		On-Demand Self-Test
AUSFORD	Australia	2011	Falcon G6E 4.0L Turbo FG			PCM -POWERTRAIN CONTROL MODULE			X	X	X		KOEO On Demand Self-Test KOER On Demand Self-Test Reset KAM
AUSFORD	Australia	2011	Falcon G6E 4.0L Turbo FG			TCM -TRANS CONTROL MODULE			X	X	X		KOEO On Demand Self-Test KOER On Demand Self-Test
AUSFORD	Australia	2011	Falcon G6E 4.0L Turbo FG			ABS -ANTILOCK BRAKE MODULE			X	X	X		On-Demand Self-Test ABS Service Bleed Steering angle sensor

Mark X Description Function is supported.

AUSFORD	Australia	2011	Falcon G6E 4.0L Turbo FG			RCM -RESTRAINT CONTROL MODULE			X	X	X		On-Demand Self-Test
AUSFORD	Australia	2011	Falcon G6E 4.0L Turbo FG			BEM -BODY ELECTRIC MODULE			X	X	X		On-Demand Self-Test Erase and Program Keys PCM Parameter Reset
AUSFORD	Australia	2011	Falcon G6E 4.0L Turbo FG			ICM -INSTRUMENT CLUSTER MODULE			X	X	X		On-Demand Self-Test
AUSFORD	Australia	2011	Falcon G6E 4.0L Turbo FG			HIM -HVAC INTEGRATED MODULE			X	X	X		On-Demand Self-Test
AUSFORD	Australia	2011	Falcon G6E 4.1L Turbo FG			ACM -AUDIO CONTROL MODULE		X	X	X	X		On-Demand Self-Test
AUSFORD	Australia	2011	Falcon G6E 4.1L Turbo FG			AIM -AUDIO INTERFACE MODULE			X	X	X		On-Demand Self-Test
AUSFORD	Australia	2011	Falcon G6E 4.1L Turbo FG			FDIM -FRONT DISPLAY INTERFACE MODULE			X	X	X		On-Demand Self-Test
AUSFORD	Australia	2011	Falcon G6E 4.1L Turbo FG			BPM -BLUETOOTH PHONE MODULE			X	X	X		On-Demand Self-Test
AUSFORD	Australia	2010	Falcon G6E 4.0L Turbo FG			PCM -POWERTRAIN CONTROL MODULE			X	X	X		KOEO On Demand Self-Test KOER On Demand Self-Test Reset KAM
AUSFORD	Australia	2010	Falcon G6E 4.0L Turbo FG			TCM -TRANS CONTROL MODULE			X	X	X		KOEO On Demand Self-Test KOER On Demand Self-Test
AUSFORD	Australia	2010	Falcon G6E 4.0L Turbo FG			ABS -ANTILOCK BRAKE MODULE			X	X	X		On-Demand Self-Test ABS Service Bleed Steering angle sensor
AUSFORD	Australia	2010	Falcon G6E 4.0L Turbo FG			RCM -RESTRAINT CONTROL MODULE			X	X	X		On-Demand Self-Test
AUSFORD	Australia	2010	Falcon G6E 4.0L Turbo FG			BEM -BODY ELECTRIC MODULE			X	X	X		On-Demand Self-Test Erase and Program Keys PCM Parameter Reset
AUSFORD	Australia	2010	Falcon G6E 4.0L Turbo FG			ICM -INSTRUMENT CLUSTER MODULE			X	X	X		On-Demand Self-Test

Mark X Description Function is supported.

AUSFORD	Australia	2010	Falcon G6E 4.0L Turbo FG			HIM -HVAC INITEGRAED MODULE			X	X	X		On-Demand Self-Test
AUSFORD	Australia	2010	Falcon G6E 4.1L Turbo FG			ACM -AUDIO CONTROL MODULE		X	X	X	X		On-Demand Self-Test
AUSFORD	Australia	2010	Falcon G6E 4.1L Turbo FG			AIM -AUDIO INTERFACE MODULE			X	X	X		On-Demand Self-Test
AUSFORD	Australia	2010	Falcon G6E 4.1L Turbo FG			FDIM -FRONT DISPLAY INTERFACE MODULE			X	X	X		On-Demand Self-Test
AUSFORD	Australia	2010	Falcon G6E 4.1L Turbo FG			BPM -BLUETOOTH PHONE MODULE			X	X	X		On-Demand Self-Test
AUSFORD	Australia	2009	Falcon G6E 4.0L Turbo FG			BEM -BODY ELECTRIC MODULE			X	X	X		KOEO On Demand Self-Test Erase and Program Keys PCM Parameter Reset
AUSFORD	Australia	2009	Falcon G6E 4.0L Turbo FG			ABS -ANTILOCK BRAKE MODULE			X	X	X		KOEO On Demand Self-Test ABS Service Bleed Steering angle sensor calibration
AUSFORD	Australia	2009	FALCON XT 4.0L BF			PCM -POWERTRAIN CONTROL MODULE			X	X	X		KOEO On Demand Self-Test KOER On Demand Self-Test
AUSFORD	Australia	2009	FALCON XT 4.0L BF			TCM -TRANS CONTROL MODULE			X	X	X		On-Demand Self-Test
AUSFORD	Australia	2009	FALCON XT 4.0L BF			ABS -ANTILOCK BRAKE MODULE		X	X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2009	FALCON XT 4.0L BF			RCM -RESTRAINT CONTROL MODULE			X	X	X		On-Demand Self-Test
AUSFORD	Australia	2009	FALCON XT 4.0L BF			BEM -BODY ELECTRIC MODULE		X	X	X	X		On-Demand Self-Test Erase and Program Keys PCM Parameter Reset
AUSFORD	Australia	2009	FALCON XT 4.0L BF			ICM -INSTRUMENT CLUSTER MODULE		X	X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2009	FALCON XT 4.0L BF			HIM -HVAC INITEGRAED MODULE		X	X	X	X		On-Demand Self-Test New HIM Installation

Mark X Description Function is supported.

AUSFORD	Australia	2009	FALCON XT 4.0L BF			ACM -AUDIO CONTROL MODULE		X	X	X	X		On-Demand Self-Test
AUSFORD	Australia	2009	FALCON XR6 4.0L BF			PCM -POWERTRAIN CONTROL MODULE			X	X	X		KOEO On Demand Self-Test KOER On Demand Self-Test
AUSFORD	Australia	2009	FALCON XR6 4.0L BF			TCM -TRANS CONTROL MODULE			X	X	X		On-Demand Self-Test
AUSFORD	Australia	2009	FALCON XR6 4.0L BF			ABS -ANTILOCK BRAKE MODULE		X	X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2009	FALCON XR6 4.0L BF			RCM -RESTRAINT CONTROL MODULE			X	X	X		On-Demand Self-Test
AUSFORD	Australia	2009	FALCON XR6 4.0L BF			BEM -BODY ELECTRIC MODULE		X	X	X	X		On-Demand Self-Test Erase and Program Keys PCM Parameter Reset
AUSFORD	Australia	2009	FALCON XR6 4.0L BF			ICM -INSTRUMENT CLUSTER MODULE		X	X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2009	FALCON XR6 4.0L BF			HIM -HVAC INITEGRAED MODULE		X	X	X	X		On-Demand Self-Test New HIM Installation
AUSFORD	Australia	2009	FALCON XR6 4.0L BF			ACM -AUDIO CONTROL MODULE		X	X	X	X		On-Demand Self-Test
AUSFORD	Australia	2009	FALCON XR8 5.0L BF			PCM -POWERTRAIN CONTROL MODULE			X	X	X		KOEO On Demand Self-Test KOER On Demand Self-Test
AUSFORD	Australia	2009	FALCON XR8 5.0L BF			TCM -TRANS CONTROL MODULE			X	X	X		On-Demand Self-Test
AUSFORD	Australia	2009	FALCON XR8 5.0L BF			ABS -ANTILOCK BRAKE MODULE		X	X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2009	FALCON XR8 5.0L BF			RCM -RESTRAINT CONTROL MODULE			X	X	X		On-Demand Self-Test
AUSFORD	Australia	2009	FALCON XR8 5.0L BF			BEM -BODY ELECTRIC MODULE		X	X	X	X		On-Demand Self-Test Erase and Program Keys PCM Parameter Reset

Mark X Description Function is supported.

AUSFORD	Australia	2009	FALCON XR8 5.0L BF			ICM -INSTRUMENT CLUSTER MODULE		X	X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2009	FALCON XR8 5.0L BF			HIM -HVAC INTEGRATED MODULE		X	X	X	X		On-Demand Self-Test New HIM Installation
AUSFORD	Australia	2009	FALCON XR8 5.0L BF			ACM -AUDIO CONTROL MODULE		X	X	X	X		On-Demand Self-Test
AUSFORD	Australia	2009	FUTURA 4.0L BF			PCM -POWERTRAIN CONTROL MODULE			X	X	X		KOEO On Demand Self-Test KOER On Demand Self-Test
AUSFORD	Australia	2009	FUTURA 4.0L BF			TCM -TRANS CONTROL MODULE			X	X	X		On-Demand Self-Test
AUSFORD	Australia	2009	FUTURA 4.0L BF			ABS -ANTILOCK BRAKE MODULE		X	X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2009	FUTURA 4.0L BF			RCM -RESTRAINT CONTROL MODULE			X	X	X		On-Demand Self-Test
AUSFORD	Australia	2009	FUTURA 4.0L BF			BEM -BODY ELECTRIC MODULE		X	X	X	X		On-Demand Self-Test Erase and Program Keys PCM Parameter Reset
AUSFORD	Australia	2009	FUTURA 4.0L BF			ICM -INSTRUMENT CLUSTER MODULE		X	X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2009	FUTURA 4.0L BF			HIM -HVAC INTEGRATED MODULE		X	X	X	X		On-Demand Self-Test New HIM Installation
AUSFORD	Australia	2009	FUTURA 4.0L BF			ACM -AUDIO CONTROL MODULE		X	X	X	X		On-Demand Self-Test
AUSFORD	Australia	2009	FAIRMONT 4.0L BF			PCM -POWERTRAIN CONTROL MODULE			X	X	X		KOEO On Demand Self-Test KOER On Demand Self-Test
AUSFORD	Australia	2009	FAIRMONT 4.0L BF			TCM -TRANS CONTROL MODULE			X	X	X		On-Demand Self-Test
AUSFORD	Australia	2009	FAIRMONT 4.0L BF			ABS -ANTILOCK BRAKE MODULE		X	X	X	X	X	On-Demand Self-Test

Mark
X Description
Function is supported.

AUSFORD	Australia	2009	FAIRMONT 4.0L BF			RCM -RESTRAINT CONTROL MODULE			X	X	X		On-Demand Self-Test
AUSFORD	Australia	2009	FAIRMONT 4.0L BF			BEM -BODY ELECTRIC MODULE		X	X	X	X		On-Demand Self-Test Erase and Program Keys PCM Parameter Reset
AUSFORD	Australia	2009	FAIRMONT 4.0L BF			ICM -INSTRUMENT CLUSTER MODULE		X	X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2009	FAIRMONT 4.0L BF			ACM -AUDIO CONTROL MODULE		X	X	X	X		On-Demand Self-Test
AUSFORD	Australia	2009	FAIRMONT 4.0L BF			HIM -HVAC INITEGRAED MODULE		X	X	X	X		On-Demand Self-Test New HIM Installation
AUSFORD	Australia	2009	FAIRMONT GHIA 4.0L BF			PCM -POWERTRAIN CONTROL MODULE			X	X	X		KOEO On Demand Self-Test KOER On Demand Self-Test
AUSFORD	Australia	2009	FAIRMONT GHIA 4.0L BF			TCM -TRANS CONTROL MODULE			X	X	X		On-Demand Self-Test
AUSFORD	Australia	2009	FAIRMONT GHIA 4.0L BF			ABS -ANTILOCK BRAKE MODULE		X	X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2009	FAIRMONT GHIA 4.0L BF			RCM -RESTRAINT CONTROL MODULE			X	X	X		On-Demand Self-Test
AUSFORD	Australia	2009	FAIRMONT GHIA 4.0L BF			BEM -BODY ELECTRIC MODULE		X	X	X	X		On-Demand Self-Test Erase and Program Keys PCM Parameter Reset
AUSFORD	Australia	2009	FAIRMONT GHIA 4.0L BF			ICM -INSTRUMENT CLUSTER MODULE		X	X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2009	FAIRMONT GHIA 4.0L BF			HIM -HVAC INITEGRAED MODULE		X	X	X	X		On-Demand Self-Test New HIM Installation
AUSFORD	Australia	2009	FAIRMONT GHIA 4.0L BF			ACM -AUDIO CONTROL MODULE		X	X	X	X		On-Demand Self-Test
AUSFORD	Australia	2009	TERRITORY 2WD			PCM -POWERTRAIN CONTROL MODULE			X	X	X		KOEO On Demand Self-Test KOER On Demand Self-Test

Mark X Description Function is supported.

AUSFORD	Australia	2009	TERRITORY 2WD			ABS -ANTILOCK BRAKE MODULE			X	X	X		On-Demand Self-Test
AUSFORD	Australia	2009	TERRITORY 2WD			RCM -RESTRAINT CONTROL MODULE			X	X	X		On-Demand Self-Test
AUSFORD	Australia	2009	TERRITORY 2WD			BEM -BODY ELECTRIC MODULE		X	X	X	X		On-Demand Self-Test Erase and Program Keys PCM Parameter Reset
AUSFORD	Australia	2009	TERRITORY 2WD			ICM -INSTRUMENT CLUSTER MODULE		X	X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2009	TERRITORY 2WD			ACM -AUDIO CONTROL MODULE		X	X	X	X		On-Demand Self-Test
AUSFORD	Australia	2009	TERRITORY 2WD			HIM -HVAC INITEGRAED MODULE		X	X	X	X		On-Demand Self-Test New HIM Installation
AUSFORD	Australia	2009	TERRITORY 4WD/AWD			PCM -POWERTRAIN CONTROL MODULE			X	X	X		KOEO On Demand Self-Test KOER On Demand Self-Test
AUSFORD	Australia	2009	TERRITORY 4WD/AWD			TCM -TRANS CONTROL MODULE			X	X	X		On-Demand Self-Test
AUSFORD	Australia	2009	TERRITORY 4WD/AWD			ABS -ANTILOCK BRAKE MODULE		X	X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2009	TERRITORY 4WD/AWD			RCM -RESTRAINT CONTROL MODULE			X	X	X		On-Demand Self-Test
AUSFORD	Australia	2009	TERRITORY 4WD/AWD			BEM -BODY ELECTRIC MODULE		X	X	X	X		On-Demand Self-Test Erase and Program Keys PCM Parameter Reset
AUSFORD	Australia	2009	TERRITORY 4WD/AWD			ICM -INSTRUMENT CLUSTER MODULE		X	X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2009	TERRITORY 4WD/AWD			ACM -AUDIO CONTROL MODULE		X	X	X	X		On-Demand Self-Test
AUSFORD	Australia	2009	TERRITORY 4WD/AWD			HIM -HVAC INITEGRAED MODULE		X	X	X	X		On-Demand Self-Test New HIM Installation

Mark X Description Function is supported.

AUSFORD	Australia	2009	Falcon G6E 4.0L Turbo FG			PCM -POWERTRAIN CONTROL MODULE			X	X	X		KOEO On Demand Self-Test KOER On Demand Self-Test Reset KAM
AUSFORD	Australia	2009	Falcon G6E 4.0L Turbo FG			BEM -BODY ELECTRIC MODULE			X	X	X		KOEO On Demand Self-Test Erase and Program Keys PCM Parameter Reset
AUSFORD	Australia	2009	Falcon G6E 4.0L Turbo FG			ABS -ANTILOCK BRAKE MODULE			X	X	X		KOEO On Demand Self-Test ABS Service Bleed Steering angle sensor calibration
AUSFORD	Australia	2008	FALCON XT 4.0L BF			PCM -POWERTRAIN CONTROL MODULE			X	X	X		KOEO On Demand Self-Test KOER On Demand Self-Test
AUSFORD	Australia	2008	FALCON XT 4.0L BF			TCM -TRANS CONTROL MODULE			X	X	X		On-Demand Self-Test
AUSFORD	Australia	2008	FALCON XT 4.0L BF			ABS -ANTILOCK BRAKE MODULE		X	X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2008	FALCON XT 4.0L BF			RCM -RESTRAINT CONTROL MODULE			X	X	X		On-Demand Self-Test
AUSFORD	Australia	2008	FALCON XT 4.0L BF			BEM -BODY ELECTRIC MODULE		X	X	X	X		On-Demand Self-Test Erase and Program Keys PCM Parameter Reset
AUSFORD	Australia	2008	FALCON XT 4.0L BF			ICM -INSTRUMENT CLUSTER MODULE		X	X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2008	FALCON XT 4.0L BF			HIM -HVAC INTEGRATED MODULE		X	X	X	X		On-Demand Self-Test New HIM Installation
AUSFORD	Australia	2008	FALCON XT 4.0L BF			ACM -AUDIO CONTROL MODULE		X	X	X	X		On-Demand Self-Test
AUSFORD	Australia	2008	FALCON XR6 4.0L BF			PCM -POWERTRAIN CONTROL MODULE			X	X	X		KOEO On Demand Self-Test KOER On Demand Self-Test
AUSFORD	Australia	2008	FALCON XR6 4.0L BF			TCM -TRANS CONTROL MODULE			X	X	X		On-Demand Self-Test

Mark X Description Function is supported.

AUSFORD	Australia	2008	FALCON XR6 4.0L BF			ABS -ANTILOCK BRAKE MODULE		X	X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2008	FALCON XR6 4.0L BF			RCM -RESTRAINT CONTROL MODULE			X	X	X		On-Demand Self-Test
AUSFORD	Australia	2008	FALCON XR6 4.0L BF			BEM -BODY ELECTRIC MODULE		X	X	X	X		On-Demand Self-Test Erase and Program Keys PCM Parameter Reset
AUSFORD	Australia	2008	FALCON XR6 4.0L BF			ICM -INSTRUMENT CLUSTER MODULE		X	X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2008	FALCON XR6 4.0L BF			HIM -HVAC INTEGRATED MODULE		X	X	X	X		On-Demand Self-Test New HIM Installation
AUSFORD	Australia	2008	FALCON XR6 4.0L BF			ACM -AUDIO CONTROL MODULE		X	X	X	X		On-Demand Self-Test
AUSFORD	Australia	2008	FALCON XR8 5.0L BF			PCM -POWERTRAIN CONTROL MODULE			X	X	X		KOEO On Demand Self-Test KOER On Demand Self-Test
AUSFORD	Australia	2008	FALCON XR8 5.0L BF			TCM -TRANS CONTROL MODULE			X	X	X		On-Demand Self-Test
AUSFORD	Australia	2008	FALCON XR8 5.0L BF			ABS -ANTILOCK BRAKE MODULE		X	X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2008	FALCON XR8 5.0L BF			RCM -RESTRAINT CONTROL MODULE			X	X	X		On-Demand Self-Test
AUSFORD	Australia	2008	FALCON XR8 5.0L BF			BEM -BODY ELECTRIC MODULE		X	X	X	X		On-Demand Self-Test Erase and Program Keys PCM Parameter Reset
AUSFORD	Australia	2008	FALCON XR8 5.0L BF			ICM -INSTRUMENT CLUSTER MODULE		X	X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2008	FALCON XR8 5.0L BF			HIM -HVAC INTEGRATED MODULE		X	X	X	X		On-Demand Self-Test New HIM Installation
AUSFORD	Australia	2008	FALCON XR8 5.0L BF			ACM -AUDIO CONTROL MODULE		X	X	X	X		On-Demand Self-Test

Mark X Description Function is supported.

AUSFORD	Australia	2008	FUTURA 4.0L BF			PCM -POWERTRAIN CONTROL MODULE			X	X	X		KOEO On Demand Self-Test KOER On Demand Self-Test
AUSFORD	Australia	2008	FUTURA 4.0L BF			TCM -TRANS CONTROL MODULE			X	X	X		On-Demand Self-Test
AUSFORD	Australia	2008	FUTURA 4.0L BF			ABS -ANTILOCK BRAKE MODULE		X	X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2008	FUTURA 4.0L BF			RCM -RESTRAINT CONTROL MODULE			X	X	X		On-Demand Self-Test
AUSFORD	Australia	2008	FUTURA 4.0L BF			BEM -BODY ELECTRIC MODULE		X	X	X	X		On-Demand Self-Test Erase and Program Keys PCM Parameter Reset
AUSFORD	Australia	2008	FUTURA 4.0L BF			ICM -INSTRUMENT CLUSTER MODULE		X	X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2008	FUTURA 4.0L BF			ACM -AUDIO CONTROL MODULE		X	X	X	X		On-Demand Self-Test
AUSFORD	Australia	2008	FUTURA 4.0L BF			HIM -HVAC INITEGRAED MODULE		X	X	X	X		On-Demand Self-Test New HIM Installation
AUSFORD	Australia	2008	FAIRMONT 4.0L BF			PCM -POWERTRAIN CONTROL MODULE			X	X	X		KOEO On Demand Self-Test KOER On Demand Self-Test
AUSFORD	Australia	2008	FAIRMONT 4.0L BF			TCM -TRANS CONTROL MODULE			X	X	X		On-Demand Self-Test
AUSFORD	Australia	2008	FAIRMONT 4.0L BF			ABS -ANTILOCK BRAKE MODULE		X	X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2008	FAIRMONT 4.0L BF			RCM -RESTRAINT CONTROL MODULE			X	X	X		On-Demand Self-Test
AUSFORD	Australia	2008	FAIRMONT 4.0L BF			BEM -BODY ELECTRIC MODULE		X	X	X	X		On-Demand Self-Test Erase and Program Keys PCM Parameter Reset
AUSFORD	Australia	2008	FAIRMONT 4.0L BF			ICM -INSTRUMENT CLUSTER MODULE		X	X	X	X	X	On-Demand Self-Test

Mark X Description Function is supported.

AUSFORD	Australia	2008	FAIRMONT 4.0L BF			HIM -HVAC INTEGRATED MODULE		X	X	X	X		On-Demand Self-Test New HIM Installation
AUSFORD	Australia	2008	FAIRMONT 4.0L BF			ACM -AUDIO CONTROL MODULE		X	X	X	X		On-Demand Self-Test
AUSFORD	Australia	2008	FAIRMONT GHIA 4.0L BF			PCM -POWERTRAIN CONTROL MODULE			X	X	X		KOEO On Demand Self-Test KOER On Demand Self-Test
AUSFORD	Australia	2008	FAIRMONT GHIA 4.0L BF			TCM -TRANS CONTROL MODULE			X	X	X		On-Demand Self-Test
AUSFORD	Australia	2008	FAIRMONT GHIA 4.0L BF			ABS -ANTILOCK BRAKE MODULE		X	X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2008	FAIRMONT GHIA 4.0L BF			RCM -RESTRAINT CONTROL MODULE			X	X	X		On-Demand Self-Test
AUSFORD	Australia	2008	FAIRMONT GHIA 4.0L BF			BEM -BODY ELECTRIC MODULE		X	X	X	X		On-Demand Self-Test Erase and Program Keys PCM Parameter Reset
AUSFORD	Australia	2008	FAIRMONT GHIA 4.0L BF			ICM -INSTRUMENT CLUSTER MODULE		X	X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2008	FAIRMONT GHIA 4.0L BF			HIM -HVAC INTEGRATED MODULE		X	X	X	X		On-Demand Self-Test New HIM Installation
AUSFORD	Australia	2008	FAIRMONT GHIA 4.0L BF			ACM -AUDIO CONTROL MODULE		X	X	X	X		On-Demand Self-Test
AUSFORD	Australia	2008	TERRITORY 2WD			PCM -POWERTRAIN CONTROL MODULE			X	X	X		KOEO On Demand Self-Test KOER On Demand Self-Test
AUSFORD	Australia	2008	TERRITORY 2WD			ABS -ANTILOCK BRAKE MODULE		X	X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2008	TERRITORY 2WD			RCM -RESTRAINT CONTROL MODULE			X	X	X		On-Demand Self-Test
AUSFORD	Australia	2008	TERRITORY 2WD			BEM -BODY ELECTRIC MODULE		X	X	X	X		On-Demand Self-Test Erase and Program Keys PCM Parameter Reset

Mark X Description Function is supported.

AUSFORD	Australia	2008	TERRITORY 2WD			ICM -INSTRUMENT CLUSTER MODULE		X	X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2008	TERRITORY 2WD			HIM -HVAC INTEGRATED MODULE		X	X	X	X		On-Demand Self-Test New HIM Installation
AUSFORD	Australia	2008	TERRITORY 2WD			ACM -AUDIO CONTROL MODULE		X	X	X	X		On-Demand Self-Test
AUSFORD	Australia	2008	TERRITORY 4WD/AWD			PCM -POWERTRAIN CONTROL MODULE			X	X	X		KOEO On Demand Self-Test KOER On Demand Self-Test
AUSFORD	Australia	2008	TERRITORY 4WD/AWD			TCM -TRANS CONTROL MODULE			X	X	X		On-Demand Self-Test
AUSFORD	Australia	2008	TERRITORY 4WD/AWD			ABS -ANTILOCK BRAKE MODULE		X	X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2008	TERRITORY 4WD/AWD			RCM -RESTRAINT CONTROL MODULE			X	X	X		On-Demand Self-Test
AUSFORD	Australia	2008	TERRITORY 4WD/AWD			BEM -BODY ELECTRIC MODULE		X	X	X	X		On-Demand Self-Test Erase and Program Keys PCM Parameter Reset
AUSFORD	Australia	2008	TERRITORY 4WD/AWD			ICM -INSTRUMENT CLUSTER MODULE		X	X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2008	TERRITORY 4WD/AWD			ACM -AUDIO CONTROL MODULE		X	X	X	X		On-Demand Self-Test
AUSFORD	Australia	2008	TERRITORY 4WD/AWD			HIM -HVAC INTEGRATED MODULE		X	X	X	X		On-Demand Self-Test New HIM Installation
AUSFORD	Australia	2007	FALCON XT 4.0L BF			PCM -POWERTRAIN CONTROL MODULE			X	X	X		KOEO On Demand Self-Test KOER On Demand Self-Test
AUSFORD	Australia	2007	FALCON XT 4.0L BF			TCM -TRANS CONTROL MODULE			X	X	X		On-Demand Self-Test
AUSFORD	Australia	2007	FALCON XT 4.0L BF			ABS -ANTILOCK BRAKE MODULE		X	X	X	X	X	On-Demand Self-Test

Mark X Description Function is supported.

AUSFORD	Australia	2007	FALCON XT 4.0L BF			RCM -RESTRAINT CONTROL MODULE		X	X	X	X		On-Demand Self-Test
AUSFORD	Australia	2007	FALCON XT 4.0L BF			BEM -BODY ELECTRIC MODULE		X	X	X	X		On-Demand Self-Test Erase and Program Keys PCM Parameter Reset
AUSFORD	Australia	2007	FALCON XT 4.0L BF			ICM -INSTRUMENT CLUSTER MODULE		X	X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2007	FALCON XT 4.0L BF			ACM -AUDIO CONTROL MODULE		X	X	X	X		On-Demand Self-Test
AUSFORD	Australia	2007	FALCON XT 4.0L BF			HIM -HVAC INITEGRAED MODULE		X	X	X	X		On-Demand Self-Test New HIM Installation
AUSFORD	Australia	2007	FALCON XR6 4.0L BF			PCM -POWERTRAIN CONTROL MODULE			X	X	X		KOEO On Demand Self-Test KOER On Demand Self-Test
AUSFORD	Australia	2007	FALCON XR6 4.0L BF			TCM -TRANS CONTROL MODULE			X	X	X		On-Demand Self-Test
AUSFORD	Australia	2007	FALCON XR6 4.0L BF			ABS -ANTILOCK BRAKE MODULE		X	X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2007	FALCON XR6 4.0L BF			RCM -RESTRAINT CONTROL MODULE		X	X	X	X		On-Demand Self-Test
AUSFORD	Australia	2007	FALCON XR6 4.0L BF			BEM -BODY ELECTRIC MODULE		X	X	X	X		On-Demand Self-Test Erase and Program Keys PCM Parameter Reset
AUSFORD	Australia	2007	FALCON XR6 4.0L BF			HIM -HVAC INITEGRAED MODULE		X	X	X	X		On-Demand Self-Test New HIM Installation
AUSFORD	Australia	2007	FALCON XR6 4.0L BF			ICM -INSTRUMENT CLUSTER MODULE		X	X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2007	FALCON XR6 4.0L BF			ACM -AUDIO CONTROL MODULE		X	X	X	X		On-Demand Self-Test
AUSFORD	Australia	2007	FALCON XR8 5.0L BF			PCM -POWERTRAIN CONTROL MODULE			X	X	X		KOEO On Demand Self-Test KOER On Demand Self-Test

Mark X Description Function is supported.

AUSFORD	Australia	2007	FALCON XR8 5.0L BF			TCM -TRANS CONTROL MODULE			X	X	X		On-Demand Self-Test
AUSFORD	Australia	2007	FALCON XR8 5.0L BF			ABS -ANTILOCK BRAKE MODULE		X	X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2007	FALCON XR8 5.0L BF			RCM -RESTRAINT CONTROL MODULE		X	X	X	X		On-Demand Self-Test
AUSFORD	Australia	2007	FALCON XR8 5.0L BF			BEM -BODY ELECTRIC MODULE		X	X	X	X		On-Demand Self-Test Erase and Program Keys PCM Parameter Reset
AUSFORD	Australia	2007	FALCON XR8 5.0L BF			HIM -HVAC INTEGRATED MODULE		X	X	X	X		On-Demand Self-Test New HIM Installation
AUSFORD	Australia	2007	FALCON XR8 5.0L BF			ICM -INSTRUMENT CLUSTER MODULE		X	X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2007	FALCON XR8 5.0L BF			ACM -AUDIO CONTROL MODULE		X	X	X	X		On-Demand Self-Test
AUSFORD	Australia	2007	FUTURA 4.0L BF			PCM -POWERTRAIN CONTROL MODULE			X	X	X		KOEO On Demand Self-Test KOER On Demand Self-Test
AUSFORD	Australia	2007	FUTURA 4.0L BF			TCM -TRANS CONTROL MODULE			X	X	X		On-Demand Self-Test
AUSFORD	Australia	2007	FUTURA 4.0L BF			ABS -ANTILOCK BRAKE MODULE		X	X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2007	FUTURA 4.0L BF			RCM -RESTRAINT CONTROL MODULE		X	X	X	X		On-Demand Self-Test
AUSFORD	Australia	2007	FUTURA 4.0L BF			BEM -BODY ELECTRIC MODULE		X	X	X	X		On-Demand Self-Test Erase and Program Keys PCM Parameter Reset
AUSFORD	Australia	2007	FUTURA 4.0L BF			HIM -HVAC INTEGRATED MODULE		X	X	X	X		On-Demand Self-Test New HIM Installation
AUSFORD	Australia	2007	FUTURA 4.0L BF			ICM -INSTRUMENT CLUSTER MODULE		X	X	X	X	X	On-Demand Self-Test

Mark X Description Function is supported.

AUSFORD	Australia	2007	FUTURA 4.0L BF			ACM -AUDIO CONTROL MODULE		X	X	X	X		On-Demand Self-Test
AUSFORD	Australia	2007	FAIRMONT 4.0L BF			PCM -POWERTRAIN CONTROL MODULE			X	X	X		KOEO On Demand Self-Test KOER On Demand Self-Test
AUSFORD	Australia	2007	FAIRMONT 4.0L BF			TCM -TRANS CONTROL MODULE			X	X	X		On-Demand Self-Test
AUSFORD	Australia	2007	FAIRMONT 4.0L BF			ABS -ANTILOCK BRAKE MODULE		X	X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2007	FAIRMONT 4.0L BF			RCM -RESTRAINT CONTROL MODULE		X	X	X	X		On-Demand Self-Test
AUSFORD	Australia	2007	FAIRMONT 4.0L BF			BEM -BODY ELECTRIC MODULE		X	X	X	X		On-Demand Self-Test Erase and Program Keys PCM Parameter Reset
AUSFORD	Australia	2007	FAIRMONT 4.0L BF			HIM -HVAC INTEGRATED MODULE		X	X	X	X		On-Demand Self-Test New HIM Installation
AUSFORD	Australia	2007	FAIRMONT 4.0L BF			ICM -INSTRUMENT CLUSTER MODULE		X	X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2007	FAIRMONT 4.0L BF			ACM -AUDIO CONTROL MODULE		X	X	X	X		On-Demand Self-Test
AUSFORD	Australia	2007	FAIRMONT GHIA 4.0L BF			PCM -POWERTRAIN CONTROL MODULE			X	X	X		KOEO On Demand Self-Test KOER On Demand Self-Test
AUSFORD	Australia	2007	FAIRMONT GHIA 4.0L BF			TCM -TRANS CONTROL MODULE			X	X	X		On-Demand Self-Test
AUSFORD	Australia	2007	FAIRMONT GHIA 4.0L BF			ABS -ANTILOCK BRAKE MODULE		X	X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2007	FAIRMONT GHIA 4.0L BF			RCM -RESTRAINT CONTROL MODULE		X	X	X	X		On-Demand Self-Test
AUSFORD	Australia	2007	FAIRMONT GHIA 4.0L BF			BEM -BODY ELECTRIC MODULE		X	X	X	X		On-Demand Self-Test Erase and Program Keys PCM Parameter Reset

Mark
X Description
Function is supported.

AUSFORD	Australia	2007	FAIRMONT GHIA 4.0L BF			HIM -HVAC INITEGRAED MODULE		X	X	X	X		On-Demand Self-Test New HIM Installation
AUSFORD	Australia	2007	FAIRMONT GHIA 4.0L BF			ICM -INSTRUMENT CLUSTER MODULE		X	X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2007	FAIRMONT GHIA 4.0L BF			ACM -AUDIO CONTROL MODULE		X	X	X	X		On-Demand Self-Test
AUSFORD	Australia	2007	TERRITORY 2WD			PCM -POWERTRAIN CONTROL MODULE			X	X	X		KOEO On Demand Self-Test KOER On Demand Self-Test
AUSFORD	Australia	2007	TERRITORY 2WD			ABS -ANTILOCK BRAKE MODULE		X	X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2007	TERRITORY 2WD			RCM -RESTRAINT CONTROL MODULE		X	X	X	X		On-Demand Self-Test
AUSFORD	Australia	2007	TERRITORY 2WD			BEM -BODY ELECTRIC MODULE		X	X	X	X		On-Demand Self-Test Erase and Program Keys PCM Parameter Reset
AUSFORD	Australia	2007	TERRITORY 2WD			HIM -HVAC INITEGRAED MODULE		X	X	X	X		On-Demand Self-Test New HIM Installation
AUSFORD	Australia	2007	TERRITORY 2WD			ICM -INSTRUMENT CLUSTER MODULE		X	X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2007	TERRITORY 2WD			ACM -AUDIO CONTROL MODULE		X	X	X	X		On-Demand Self-Test
AUSFORD	Australia	2007	TERRITORY 4WD/AWD			PCM -POWERTRAIN CONTROL MODULE			X	X	X		KOEO On Demand Self-Test KOER On Demand Self-Test
AUSFORD	Australia	2007	TERRITORY 4WD/AWD			TCM -TRANS CONTROL MODULE			X	X	X		On-Demand Self-Test
AUSFORD	Australia	2007	TERRITORY 4WD/AWD			ABS -ANTILOCK BRAKE MODULE		X	X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2007	TERRITORY 4WD/AWD			RCM -RESTRAINT CONTROL MODULE		X	X	X	X		On-Demand Self-Test

Mark X Description Function is supported.

AUSFORD	Australia	2007	TERRITORY 4WD/AWD			BEM -BODY ELECTRIC MODULE		X	X	X	X		On-Demand Self-Test Erase and Program Keys PCM Parameter Reset
AUSFORD	Australia	2007	TERRITORY 4WD/AWD			HIM -HVAC INTEGRATED MODULE		X	X	X	X		On-Demand Self-Test New HIM Installation
AUSFORD	Australia	2007	TERRITORY 4WD/AWD			ICM -INSTRUMENT CLUSTER MODULE		X	X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2007	TERRITORY 4WD/AWD			ACM -AUDIO CONTROL MODULE		X	X	X	X		On-Demand Self-Test
AUSFORD	Australia	2006	FALCON XT 4.0L BF			PCM -POWERTRAIN CONTROL MODULE			X	X	X		KOEO On Demand Self-Test KOER On Demand Self-Test
AUSFORD	Australia	2006	FALCON XT 4.0L BF			TCM -TRANS CONTROL MODULE			X	X	X		On-Demand Self-Test
AUSFORD	Australia	2006	FALCON XT 4.0L BF			ABS -ANTILOCK BRAKE MODULE		X	X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2006	FALCON XT 4.0L BF			RCM -RESTRAINT CONTROL MODULE		X	X	X	X		On-Demand Self-Test
AUSFORD	Australia	2006	FALCON XT 4.0L BF			BEM -BODY ELECTRIC MODULE		X	X	X	X		On-Demand Self-Test Erase and Program Keys PCM Parameter Reset
AUSFORD	Australia	2006	FALCON XT 4.0L BF			HIM -HVAC INTEGRATED MODULE		X	X	X	X		On-Demand Self-Test New HIM Installation
AUSFORD	Australia	2006	FALCON XT 4.0L BF			ICM -INSTRUMENT CLUSTER MODULE		X	X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2006	FALCON XT 4.0L BF			ACM -AUDIO CONTROL MODULE		X	X	X	X		On-Demand Self-Test
AUSFORD	Australia	2006	FALCON XR6 4.0L BF			PCM -POWERTRAIN CONTROL MODULE			X	X	X		KOEO On Demand Self-Test KOER On Demand Self-Test
AUSFORD	Australia	2006	FALCON XR6 4.0L BF			TCM -TRANS CONTROL MODULE			X	X	X		On-Demand Self-Test

Mark X Description Function is supported.

AUSFORD	Australia	2006	FALCON XR6 4.0L BF			ABS -ANTILOCK BRAKE MODULE		X	X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2006	FALCON XR6 4.0L BF			RCM -RESTRAINT CONTROL MODULE		X	X	X	X		On-Demand Self-Test
AUSFORD	Australia	2006	FALCON XR6 4.0L BF			BEM -BODY ELECTRIC MODULE		X	X	X	X		On-Demand Self-Test Erase and Program Keys PCM Parameter Reset
AUSFORD	Australia	2006	FALCON XR6 4.0L BF			HIM -HVAC INTEGRATED MODULE		X	X	X	X		On-Demand Self-Test New HIM Installation
AUSFORD	Australia	2006	FALCON XR6 4.0L BF			ICM -INSTRUMENT CLUSTER MODULE		X	X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2006	FALCON XR6 4.0L BF			ACM -AUDIO CONTROL MODULE		X	X	X	X		On-Demand Self-Test
AUSFORD	Australia	2006	FALCON XR8 5.0L BF			PCM -POWERTRAIN CONTROL MODULE			X	X	X		KOEO On Demand Self-Test KOER On Demand Self-Test
AUSFORD	Australia	2006	FALCON XR8 5.0L BF			TCM -TRANS CONTROL MODULE			X	X	X		On-Demand Self-Test
AUSFORD	Australia	2006	FALCON XR8 5.0L BF			ABS -ANTILOCK BRAKE MODULE		X	X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2006	FALCON XR8 5.0L BF			RCM -RESTRAINT CONTROL MODULE		X	X	X	X		On-Demand Self-Test
AUSFORD	Australia	2006	FALCON XR8 5.0L BF			BEM -BODY ELECTRIC MODULE		X	X	X	X		On-Demand Self-Test Erase and Program Keys PCM Parameter Reset
AUSFORD	Australia	2006	FALCON XR8 5.0L BF			HIM -HVAC INTEGRATED MODULE		X	X	X	X		On-Demand Self-Test New HIM Installation
AUSFORD	Australia	2006	FALCON XR8 5.0L BF			ICM -INSTRUMENT CLUSTER MODULE		X	X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2006	FALCON XR8 5.0L BF			ACM -AUDIO CONTROL MODULE		X	X	X	X		On-Demand Self-Test

Mark X Description Function is supported.

AUSFORD	Australia	2006	FUTURA 4.0L BF			PCM -POWERTRAIN CONTROL MODULE			X	X	X		KOEO On Demand Self-Test KOER On Demand Self-Test
AUSFORD	Australia	2006	FUTURA 4.0L BF			TCM -TRANS CONTROL MODULE			X	X	X		On-Demand Self-Test
AUSFORD	Australia	2006	FUTURA 4.0L BF			ABS -ANTILOCK BRAKE MODULE		X	X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2006	FUTURA 4.0L BF			RCM -RESTRAINT CONTROL MODULE		X	X	X	X		On-Demand Self-Test
AUSFORD	Australia	2006	FUTURA 4.0L BF			BEM -BODY ELECTRIC MODULE		X	X	X	X		On-Demand Self-Test Erase and Program Keys PCM Parameter Reset
AUSFORD	Australia	2006	FUTURA 4.0L BF			HIM -HVAC INITEGRAED MODULE		X	X	X	X		On-Demand Self-Test New HIM Installation
AUSFORD	Australia	2006	FUTURA 4.0L BF			ICM -INSTRUMENT CLUSTER MODULE		X	X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2006	FUTURA 4.0L BF			ACM -AUDIO CONTROL MODULE		X	X	X	X		On-Demand Self-Test
AUSFORD	Australia	2006	FAIRMONT 4.0L BF			PCM -POWERTRAIN CONTROL MODULE			X	X	X		KOEO On Demand Self-Test KOER On Demand Self-Test
AUSFORD	Australia	2006	FAIRMONT 4.0L BF			TCM -TRANS CONTROL MODULE			X	X	X		On-Demand Self-Test
AUSFORD	Australia	2006	FAIRMONT 4.0L BF			ABS -ANTILOCK BRAKE MODULE		X	X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2006	FAIRMONT 4.0L BF			RCM -RESTRAINT CONTROL MODULE		X	X	X	X		On-Demand Self-Test
AUSFORD	Australia	2006	FAIRMONT 4.0L BF			BEM -BODY ELECTRIC MODULE		X	X	X	X		On-Demand Self-Test Erase and Program Keys PCM Parameter Reset
AUSFORD	Australia	2006	FAIRMONT 4.0L BF			HIM -HVAC INITEGRAED MODULE		X	X	X	X		On-Demand Self-Test New HIM Installation

Mark X Description Function is supported.

AUSFORD	Australia	2006	FAIRMONT 4.0L BF			ICM -INSTRUMENT CLUSTER MODULE		X	X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2006	FAIRMONT 4.0L BF			ACM -AUDIO CONTROL MODULE		X	X	X	X		On-Demand Self-Test
AUSFORD	Australia	2006	FAIRMONT GHIA 4.0L BF			PCM -POWERTRAIN CONTROL MODULE			X	X	X		KOEO On Demand Self-Test KOER On Demand Self-Test
AUSFORD	Australia	2006	FAIRMONT GHIA 4.0L BF			TCM -TRANS CONTROL MODULE			X	X	X		On-Demand Self-Test
AUSFORD	Australia	2006	FAIRMONT GHIA 4.0L BF			ABS -ANTILOCK BRAKE MODULE		X	X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2006	FAIRMONT GHIA 4.0L BF			RCM -RESTRAINT CONTROL MODULE		X	X	X	X		On-Demand Self-Test
AUSFORD	Australia	2006	FAIRMONT GHIA 4.0L BF			BEM -BODY ELECTRIC MODULE		X	X	X	X		On-Demand Self-Test Erase and Program Keys PCM Parameter Reset
AUSFORD	Australia	2006	FAIRMONT GHIA 4.0L BF			HIM -HVAC INITEGRAED MODULE		X	X	X	X		On-Demand Self-Test New HIM Installation
AUSFORD	Australia	2006	FAIRMONT GHIA 4.0L BF			ICM -INSTRUMENT CLUSTER MODULE		X	X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2006	FAIRMONT GHIA 4.0L BF			ACM -AUDIO CONTROL MODULE		X	X	X	X		On-Demand Self-Test
AUSFORD	Australia	2006	TERRITORY 2WD			PCM -POWERTRAIN CONTROL MODULE			X	X	X		KOEO On Demand Self-Test KOER On Demand Self-Test
AUSFORD	Australia	2006	TERRITORY 2WD			ABS -ANTILOCK BRAKE MODULE		X	X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2006	TERRITORY 2WD			RCM -RESTRAINT CONTROL MODULE		X	X	X	X		On-Demand Self-Test
AUSFORD	Australia	2006	TERRITORY 2WD			BEM -BODY ELECTRIC MODULE		X	X	X	X		On-Demand Self-Test Erase and Program Keys PCM Parameter Reset

Mark X Description Function is supported.

AUSFORD	Australia	2006	TERRITORY 2WD			HIM -HVAC INTEGRATED MODULE		X	X	X	X		On-Demand Self-Test New HIM Installation
AUSFORD	Australia	2006	TERRITORY 2WD			ICM -INSTRUMENT CLUSTER MODULE		X	X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2006	TERRITORY 2WD			ACM -AUDIO CONTROL MODULE		X	X	X	X		On-Demand Self-Test
AUSFORD	Australia	2006	TERRITORY 4WD/AWD			PCM -POWERTRAIN CONTROL MODULE			X	X	X		KOEO On Demand Self-Test KOER On Demand Self-Test
AUSFORD	Australia	2006	TERRITORY 4WD/AWD			TCM -TRANS CONTROL MODULE			X	X	X		On-Demand Self-Test
AUSFORD	Australia	2006	TERRITORY 4WD/AWD			ABS -ANTILOCK BRAKE MODULE		X	X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2006	TERRITORY 4WD/AWD			RCM -RESTRAINT CONTROL MODULE		X	X	X	X		On-Demand Self-Test
AUSFORD	Australia	2006	TERRITORY 4WD/AWD			BEM -BODY ELECTRIC MODULE		X	X	X	X		On-Demand Self-Test Erase and Program Keys PCM Parameter Reset
AUSFORD	Australia	2006	TERRITORY 4WD/AWD			HIM -HVAC INTEGRATED MODULE		X	X	X	X		On-Demand Self-Test New HIM Installation
AUSFORD	Australia	2006	TERRITORY 4WD/AWD			ICM -INSTRUMENT CLUSTER MODULE		X	X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2006	TERRITORY 4WD/AWD			ACM -AUDIO CONTROL MODULE		X	X	X	X		On-Demand Self-Test
AUSFORD	Australia	2006	FOCUS 2.0L			PCM -POWERTRAIN CONTROL MODULE			X	X	X		KOEO On Demand Self-Test KOER On Demand Self-Test
AUSFORD	Australia	2006	FOCUS 2.0L			TCM -TRANS CONTROL MODULE			X	X	X		On-Demand Self-Test
AUSFORD	Australia	2006	FOCUS 2.0L			ABS -ANTILOCK BRAKE MODULE			X	X	X		On-Demand Self-Test

Mark X Description Function is supported.

AUSFORD	Australia	2006	FOCUS 2.0L			RCM -RESTRAINT CONTROL MODULE			X	X	X		On-Demand Self-Test
AUSFORD	Australia	2006	FOCUS 2.0L			ICM -INSTRUMENT CLUSTER MODULE			X	X	X		On-Demand Self-Test
AUSFORD	Australia	2005	FALCON XT 4.0L BA			PCM -POWERTRAIN CONTROL MODULE			X	X	X		KOEO On Demand Self-Test KOER On Demand Self-Test
AUSFORD	Australia	2005	FALCON XT 4.0L BA			ABS -ANTILOCK BRAKE MODULE		X	X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2005	FALCON XT 4.0L BA			RCM -RESTRAINT CONTROL MODULE			X	X	X		On-Demand Self-Test
AUSFORD	Australia	2005	FALCON XT 4.0L BA			BEM -BODY ELECTRIC MODULE		X	X	X	X		On-Demand Self-Test New BEM Installation Erase and Program Keys PCM Parameter Reset
AUSFORD	Australia	2005	FALCON XT 4.0L BA			HIM -HVAC INITEGRAED MODULE		X	X	X	X		On-Demand Self-Test New HIM Installation
AUSFORD	Australia	2005	FALCON XT 4.0L BA			ICM -INSTRUMENT CLUSTER MODULE		X	X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2005	FALCON XT 4.0L BA			ACM -AUDIO CONTROL MODULE		X	X	X	X		On-Demand Self-Test
AUSFORD	Australia	2005	FALCON XR6 4.0L BA			PCM -POWERTRAIN CONTROL MODULE			X	X	X		KOEO On Demand Self-Test KOER On Demand Self-Test
AUSFORD	Australia	2005	FALCON XR6 4.0L BA			ABS -ANTILOCK BRAKE MODULE		X	X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2005	FALCON XR6 4.0L BA			RCM -RESTRAINT CONTROL MODULE			X	X	X		On-Demand Self-Test
AUSFORD	Australia	2005	FALCON XR6 4.0L BA			BEM -BODY ELECTRIC MODULE		X	X	X	X		On-Demand Self-Test New BEM Installation Erase and Program Keys PCM Parameter Reset

Mark X Description Function is supported.

AUSFORD	Australia	2005	FALCON XR6 4.0L BA			HIM -HVAC INITEGRAED MODULE		X	X	X	X		On-Demand Self-Test New HIM Installation
AUSFORD	Australia	2005	FALCON XR6 4.0L BA			ICM -INSTRUMENT CLUSTER MODULE		X	X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2005	FALCON XR6 4.0L BA			ACM -AUDIO CONTROL MODULE		X	X	X	X		On-Demand Self-Test
AUSFORD	Australia	2005	FALCON XR8 5.0L BA			PCM -POWERTRAIN CONTROL MODULE			X	X	X		KOEO On Demand Self-Test KOER On Demand Self-Test
AUSFORD	Australia	2005	FALCON XR8 5.0L BA			ABS -ANTILOCK BRAKE MODULE		X	X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2005	FALCON XR8 5.0L BA			RCM -RESTRAINT CONTROL MODULE			X	X	X		On-Demand Self-Test
AUSFORD	Australia	2005	FALCON XR8 5.0L BA			BEM -BODY ELECTRIC MODULE		X	X	X	X		On-Demand Self-Test New BEM Installation Erase and Program Keys PCM Parameter Reset
AUSFORD	Australia	2005	FALCON XR8 5.0L BA			HIM -HVAC INITEGRAED MODULE		X	X	X	X		On-Demand Self-Test New HIM Installation
AUSFORD	Australia	2005	FALCON XR8 5.0L BA			ICM -INSTRUMENT CLUSTER MODULE		X	X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2005	FALCON XR8 5.0L BA			ACM -AUDIO CONTROL MODULE		X	X	X	X		On-Demand Self-Test
AUSFORD	Australia	2005	FUTURA 4.0L BA			PCM -POWERTRAIN CONTROL MODULE			X	X	X		KOEO On Demand Self-Test KOER On Demand Self-Test
AUSFORD	Australia	2005	FUTURA 4.0L BA			ABS -ANTILOCK BRAKE MODULE		X	X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2005	FUTURA 4.0L BA			RCM -RESTRAINT CONTROL MODULE			X	X	X		On-Demand Self-Test
AUSFORD	Australia	2005	FUTURA 4.0L BA			BEM -BODY ELECTRIC MODULE		X	X	X	X		On-Demand Self-Test New BEM

Mark X Description Function is supported.

Mark	Description		Function is supported.											
														Installation Erase and Program Keys PCM Parameter Reset
AUSFORD	Australia	2005	FUTURA 4.0L BA			HIM -HVAC INTEGRATED MODULE		X	X	X	X			On-Demand Self-Test New HIM Installation
AUSFORD	Australia	2005	FUTURA 4.0L BA			ICM -INSTRUMENT CLUSTER MODULE		X	X	X	X	X		On-Demand Self-Test
AUSFORD	Australia	2005	FUTURA 4.0L BA			ACM -AUDIO CONTROL MODULE		X	X	X	X			On-Demand Self-Test
AUSFORD	Australia	2005	FAIRMONT 4.0L BA			PCM -POWERTRAIN CONTROL MODULE			X	X	X			KOEO On Demand Self-Test KOER On Demand Self-Test
AUSFORD	Australia	2005	FAIRMONT 4.0L BA			ABS -ANTILOCK BRAKE MODULE		X	X	X	X	X		On-Demand Self-Test
AUSFORD	Australia	2005	FAIRMONT 4.0L BA			RCM -RESTRAINT CONTROL MODULE			X	X	X			On-Demand Self-Test
AUSFORD	Australia	2005	FAIRMONT 4.0L BA			BEM -BODY ELECTRIC MODULE		X	X	X	X			On-Demand Self-Test New BEM Installation Erase and Program Keys PCM Parameter Reset
AUSFORD	Australia	2005	FAIRMONT 4.0L BA			HIM -HVAC INTEGRATED MODULE		X	X	X	X			On-Demand Self-Test New HIM Installation
AUSFORD	Australia	2005	FAIRMONT 4.0L BA			ICM -INSTRUMENT CLUSTER MODULE		X	X	X	X	X		On-Demand Self-Test
AUSFORD	Australia	2005	FAIRMONT 4.0L BA			ACM -AUDIO CONTROL MODULE		X	X	X	X			On-Demand Self-Test
AUSFORD	Australia	2005	FAIRMONT GHIA 4.0L BA			PCM -POWERTRAIN CONTROL MODULE			X	X	X			KOEO On Demand Self-Test KOER On Demand Self-Test
AUSFORD	Australia	2005	FAIRMONT GHIA 4.0L BA			ABS -ANTILOCK BRAKE MODULE		X	X	X	X	X		On-Demand Self-Test
AUSFORD	Australia	2005	FAIRMONT GHIA 4.0L BA			RCM -RESTRAINT CONTROL			X	X	X			On-Demand Self-Test

Mark X Description Function is supported.

Mark	Description	Function is supported.											
						MODULE							
AUSFORD	Australia	2005	FAIRMONT GHIA 4.0L BA			BEM -BODY ELECTRIC MODULE		X	X	X	X		On-Demand Self-Test New BEM Installation Erase and Program Keys PCM Parameter Reset
AUSFORD	Australia	2005	FAIRMONT GHIA 4.0L BA			HIM -HVAC INITEGRAED MODULE		X	X	X	X		On-Demand Self-Test New HIM Installation
AUSFORD	Australia	2005	FAIRMONT GHIA 4.0L BA			ICM -INSTRUMENT CLUSTER MODULE		X	X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2005	FAIRMONT GHIA 4.0L BA			ACM -AUDIO CONTROL MODULE		X	X	X	X		On-Demand Self-Test
AUSFORD	Australia	2005	TERRITORY 2WD			PCM -POWERTRAIN CONTROL MODULE			X	X	X		KOEO On Demand Self-Test KOER On Demand Self-Test
AUSFORD	Australia	2005	TERRITORY 2WD			ABS -ANTILOCK BRAKE MODULE		X	X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2005	TERRITORY 2WD			RCM -RESTRAINT CONTROL MODULE			X	X	X		On-Demand Self-Test
AUSFORD	Australia	2005	TERRITORY 2WD			BEM -BODY ELECTRIC MODULE		X	X	X	X		On-Demand Self-Test New BEM Installation Erase and Program Keys PCM Parameter Reset
AUSFORD	Australia	2005	TERRITORY 2WD			HIM -HVAC INITEGRAED MODULE		X	X	X	X		On-Demand Self-Test New HIM Installation
AUSFORD	Australia	2005	TERRITORY 2WD			ICM -INSTRUMENT CLUSTER MODULE		X	X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2005	TERRITORY 2WD			ACM -AUDIO CONTROL MODULE		X	X	X	X		On-Demand Self-Test
AUSFORD	Australia	2005	TERRITORY 4WD/AWD			PCM -POWERTRAIN CONTROL MODULE			X	X	X		KOEO On Demand Self-Test KOER On Demand Self-Test

Mark X Description Function is supported.

AUSFORD	Australia	2005	TERRITORY 4WD/AWD			TCM -TRANS CONTROL MODULE			X	X	X		On-Demand Self-Test
AUSFORD	Australia	2005	TERRITORY 4WD/AWD			ABS -ANTILOCK BRAKE MODULE		X	X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2005	TERRITORY 4WD/AWD			RCM -RESTRAINT CONTROL MODULE			X	X	X		On-Demand Self-Test
AUSFORD	Australia	2005	TERRITORY 4WD/AWD			BEM -BODY ELECTRIC MODULE		X	X	X	X		On-Demand Self-Test New BEM Installation Erase and Program Keys PCM Parameter Reset
AUSFORD	Australia	2005	TERRITORY 4WD/AWD			HIM -HVAC INTEGRATED MODULE		X	X	X	X		On-Demand Self-Test New HIM Installation
AUSFORD	Australia	2005	TERRITORY 4WD/AWD			ICM -INSTRUMENT CLUSTER MODULE		X	X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2005	TERRITORY 4WD/AWD			ACM -AUDIO CONTROL MODULE		X	X	X	X		On-Demand Self-Test
AUSFORD	Australia	2004	FALCON XT 4.0L BA			PCM -POWERTRAIN CONTROL MODULE			X	X	X		KOEO On Demand Self-Test KOER On Demand Self-Test
AUSFORD	Australia	2004	FALCON XT 4.0L BA			ABS -ANTILOCK BRAKE MODULE		X	X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2004	FALCON XT 4.0L BA			RCM -RESTRAINT CONTROL MODULE			X	X	X		On-Demand Self-Test
AUSFORD	Australia	2004	FALCON XT 4.0L BA			BEM -BODY ELECTRIC MODULE		X	X	X	X		On-Demand Self-Test New BEM Installation Erase and Program Keys PCM Parameter Reset
AUSFORD	Australia	2004	FALCON XT 4.0L BA			HIM -HVAC INTEGRATED MODULE		X	X	X	X		On-Demand Self-Test New HIM Installation
AUSFORD	Australia	2004	FALCON XT 4.0L BA			ICM -INSTRUMENT CLUSTER MODULE		X	X	X	X	X	On-Demand Self-Test

Mark X Description Function is supported.

AUSFORD	Australia	2004	FALCON XT 4.0L BA			ACM -AUDIO CONTROL MODULE		X	X	X	X		On-Demand Self-Test
AUSFORD	Australia	2004	FALCON XR6 4.0L BA			PCM -POWERTRAIN CONTROL MODULE			X	X	X		KOEO On Demand Self-Test KOER On Demand Self-Test
AUSFORD	Australia	2004	FALCON XR6 4.0L BA			ABS -ANTILOCK BRAKE MODULE		X	X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2004	FALCON XR6 4.0L BA			RCM -RESTRAINT CONTROL MODULE			X	X	X		On-Demand Self-Test
AUSFORD	Australia	2004	FALCON XR6 4.0L BA			BEM -BODY ELECTRIC MODULE		X	X	X	X		On-Demand Self-Test New BEM Installation Erase and Program Keys PCM Parameter Reset
AUSFORD	Australia	2004	FALCON XR6 4.0L BA			HIM -HVAC INTEGRATED MODULE		X	X	X	X		On-Demand Self-Test New HIM Installation
AUSFORD	Australia	2004	FALCON XR6 4.0L BA			ICM -INSTRUMENT CLUSTER MODULE		X	X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2004	FALCON XR6 4.0L BA			ACM -AUDIO CONTROL MODULE		X	X	X	X		On-Demand Self-Test
AUSFORD	Australia	2004	FALCON XR8 5.0L BA			PCM -POWERTRAIN CONTROL MODULE			X	X	X		KOEO On Demand Self-Test KOER On Demand Self-Test
AUSFORD	Australia	2004	FALCON XR8 5.0L BA			ABS -ANTILOCK BRAKE MODULE		X	X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2004	FALCON XR8 5.0L BA			RCM -RESTRAINT CONTROL MODULE			X	X	X		On-Demand Self-Test
AUSFORD	Australia	2004	FALCON XR8 5.0L BA			BEM -BODY ELECTRIC MODULE		X	X	X	X		On-Demand Self-Test New BEM Installation Erase and Program Keys PCM Parameter Reset
AUSFORD	Australia	2004	FALCON XR8 5.0L BA			HIM -HVAC INTEGRATED MODULE		X	X	X	X		On-Demand Self-Test New HIM Installation

Mark
X Description
Function is supported.

Mark	Description												
X	Function is supported.												
AUSFORD	Australia	2004	FALCON XR8 5.0L BA			ICM -INSTRUMENT CLUSTER MODULE		X	X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2004	FALCON XR8 5.0L BA			ACM -AUDIO CONTROL MODULE		X	X	X	X		On-Demand Self-Test
AUSFORD	Australia	2004	FUTURA 4.0L BA			PCM -POWERTRAIN CONTROL MODULE			X	X	X		KOEO On Demand Self-Test KOER On Demand Self-Test
AUSFORD	Australia	2004	FUTURA 4.0L BA			ABS -ANTILOCK BRAKE MODULE		X	X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2004	FUTURA 4.0L BA			RCM -RESTRAINT CONTROL MODULE			X	X	X		On-Demand Self-Test
AUSFORD	Australia	2004	FUTURA 4.0L BA			BEM -BODY ELECTRIC MODULE		X	X	X	X		On-Demand Self-Test New BEM Installation Erase and Program Keys PCM Parameter Reset
AUSFORD	Australia	2004	FUTURA 4.0L BA			HIM -HVAC INTEGRATED MODULE		X	X	X	X		On-Demand Self-Test New HIM Installation
AUSFORD	Australia	2004	FUTURA 4.0L BA			ICM -INSTRUMENT CLUSTER MODULE		X	X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2004	FUTURA 4.0L BA			ACM -AUDIO CONTROL MODULE		X	X	X	X		On-Demand Self-Test
AUSFORD	Australia	2004	FAIRMONT 4.0L BA			PCM -POWERTRAIN CONTROL MODULE			X	X	X		KOEO On Demand Self-Test KOER On Demand Self-Test
AUSFORD	Australia	2004	FAIRMONT 4.0L BA			ABS -ANTILOCK BRAKE MODULE		X	X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2004	FAIRMONT 4.0L BA			RCM -RESTRAINT CONTROL MODULE			X	X	X		On-Demand Self-Test
AUSFORD	Australia	2004	FAIRMONT 4.0L BA			BEM -BODY ELECTRIC MODULE		X	X	X	X		On-Demand Self-Test New BEM Installation Erase and Program Keys PCM Parameter Reset

Mark X Description Function is supported.

AUSFORD	Australia	2004	FAIRMONT 4.0L BA			HIM -HVAC INTEGRATED MODULE		X	X	X	X		On-Demand Self-Test New HIM Installation
AUSFORD	Australia	2004	FAIRMONT 4.0L BA			ICM -INSTRUMENT CLUSTER MODULE		X	X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2004	FAIRMONT 4.0L BA			ACM -AUDIO CONTROL MODULE		X	X	X	X		On-Demand Self-Test
AUSFORD	Australia	2004	FAIRMONT GHIA 4.0L BA			PCM -POWERTRAIN CONTROL MODULE			X	X	X		KOEO On Demand Self-Test KOER On Demand Self-Test
AUSFORD	Australia	2004	FAIRMONT GHIA 4.0L BA			ABS -ANTILOCK BRAKE MODULE		X	X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2004	FAIRMONT GHIA 4.0L BA			RCM -RESTRAINT CONTROL MODULE			X	X	X		On-Demand Self-Test
AUSFORD	Australia	2004	FAIRMONT GHIA 4.0L BA			BEM -BODY ELECTRIC MODULE		X	X	X	X		On-Demand Self-Test New BEM Installation Erase and Program Keys PCM Parameter Reset
AUSFORD	Australia	2004	FAIRMONT GHIA 4.0L BA			HIM -HVAC INTEGRATED MODULE		X	X	X	X		On-Demand Self-Test New HIM Installation
AUSFORD	Australia	2004	FAIRMONT GHIA 4.0L BA			ICM -INSTRUMENT CLUSTER MODULE		X	X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2004	FAIRMONT GHIA 4.0L BA			ACM -AUDIO CONTROL MODULE		X	X	X	X		On-Demand Self-Test
AUSFORD	Australia	2004	TERRITORY 2WD			PCM -POWERTRAIN CONTROL MODULE			X	X	X		KOEO On Demand Self-Test KOER On Demand Self-Test
AUSFORD	Australia	2004	TERRITORY 2WD			ABS -ANTILOCK BRAKE MODULE		X	X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2004	TERRITORY 2WD			RCM -RESTRAINT CONTROL MODULE			X	X	X		On-Demand Self-Test
AUSFORD	Australia	2004	TERRITORY 2WD			BEM -BODY ELECTRIC MODULE		X	X	X	X		On-Demand Self-Test New BEM

Mark X Description Function is supported.

Mark	Description	Function is supported.												
														Installation Erase and Program Keys PCM Parameter Reset
AUSFORD	Australia	2004	TERRITORY 2WD			HIM -HVAC INITEGRAED MODULE		X	X	X	X			On-Demand Self-Test New HIM Installation
AUSFORD	Australia	2004	TERRITORY 2WD			ICM -INSTRUMENT CLUSTER MODULE		X	X	X	X	X		On-Demand Self-Test
AUSFORD	Australia	2004	TERRITORY 2WD			ACM -AUDIO CONTROL MODULE		X	X	X	X			On-Demand Self-Test
AUSFORD	Australia	2004	TERRITORY 4WD/AWD			PCM -POWERTRAIN CONTROL MODULE			X	X	X			KOEO On Demand Self-Test KOER On Demand Self-Test
AUSFORD	Australia	2004	TERRITORY 4WD/AWD			TCM -TRANS CONTROL MODULE			X	X	X			On-Demand Self-Test
AUSFORD	Australia	2004	TERRITORY 4WD/AWD			ABS -ANTILOCK BRAKE MODULE		X	X	X	X	X		On-Demand Self-Test
AUSFORD	Australia	2004	TERRITORY 4WD/AWD			RCM -RESTRAINT CONTROL MODULE			X	X	X			On-Demand Self-Test
AUSFORD	Australia	2004	TERRITORY 4WD/AWD			BEM -BODY ELECTRIC MODULE		X	X	X	X			On-Demand Self-Test New BEM Installation Erase and Program Keys PCM Parameter Reset
AUSFORD	Australia	2004	TERRITORY 4WD/AWD			HIM -HVAC INITEGRAED MODULE		X	X	X	X			On-Demand Self-Test New HIM Installation
AUSFORD	Australia	2004	TERRITORY 4WD/AWD			ICM -INSTRUMENT CLUSTER MODULE		X	X	X	X	X		On-Demand Self-Test
AUSFORD	Australia	2004	TERRITORY 4WD/AWD			ACM -AUDIO CONTROL MODULE		X	X	X	X			On-Demand Self-Test
AUSFORD	Australia	2004	EXPLORER 4.0L			PCM -POWERTRAIN CONTROL MODULE			X	X	X			KOEO On Demand Self-Test KOER On Demand Self-Test
AUSFORD	Australia	2004	EXPLORER 4.0L			ABS -ANTILOCK BRAKE MODULE		X	X	X	X	X		On-Demand Self-Test

Mark X Description Function is supported.

AUSFORD	Australia	2004	EXPLORER 4.0L			RCM -RESTRAINT CONTROL MODULE			X	X	X		On-Demand Self-Test
AUSFORD	Australia	2004	EXPLORER 4.0L			BEM -BODY ELECTRIC MODULE		X	X	X	X		On-Demand Self-Test
AUSFORD	Australia	2004	EXPLORER 4.0L			ICM -INSTRUMENT CLUSTER MODULE		X	X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2004	EXPLORER 4.0L			ACM -AUDIO CONTROL MODULE		X	X	X	X		On-Demand Self-Test
AUSFORD	Australia	2003	FALCON XT 4.0L BA			PCM -POWERTRAIN CONTROL MODULE			X	X	X		KOEO On Demand Self-Test KOER On Demand Self-Test
AUSFORD	Australia	2003	FALCON XT 4.0L BA			ABS -ANTILOCK BRAKE MODULE		X	X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2003	FALCON XT 4.0L BA			RCM -RESTRAINT CONTROL MODULE			X	X	X		On-Demand Self-Test
AUSFORD	Australia	2003	FALCON XT 4.0L BA			BEM -BODY ELECTRIC MODULE		X	X	X	X		On-Demand Self-Test New BEM Installation Erase and Program Keys PCM Parameter Reset
AUSFORD	Australia	2003	FALCON XT 4.0L BA			HEC -HYBRID ELECTRIC CLUSTER		X	X	X	X		On-Demand Self-Test
AUSFORD	Australia	2003	FALCON XT 4.0L BA			ICM -INSTRUMENT CLUSTER MODULE		X	X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2003	FALCON XT 4.0L BA			ACM -AUDIO CONTROL MODULE		X	X	X	X		On-Demand Self-Test
AUSFORD	Australia	2003	FALCON XT 4.0L BA			HIM -HVAC INTEGRATED MODULE		X	X	X	X		On-Demand Self-Test New HIM Installation
AUSFORD	Australia	2003	FALCON XR6 4.0L BA			PCM -POWERTRAIN CONTROL MODULE			X	X	X		KOEO On Demand Self-Test KOER On Demand Self-Test
AUSFORD	Australia	2003	FALCON XR6 4.0L BA			ABS -ANTILOCK BRAKE MODULE		X	X	X	X	X	On-Demand Self-Test

Mark X Description Function is supported.

AUSFORD	Australia	2003	FALCON XR6 4.0L BA			RCM -RESTRAINT CONTROL MODULE			X	X	X		On-Demand Self-Test
AUSFORD	Australia	2003	FALCON XR6 4.0L BA			BEM -BODY ELECTRIC MODULE		X	X	X	X		On-Demand Self-Test New BEM Installation Erase and Program Keys PCM Parameter Reset
AUSFORD	Australia	2003	FALCON XR6 4.0L BA			HIM -HVAC INITEGRAED MODULE		X	X	X	X		On-Demand Self-Test New HIM Installation
AUSFORD	Australia	2003	FALCON XR6 4.0L BA			ICM -INSTRUMENT CLUSTER MODULE		X	X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2003	FALCON XR6 4.0L BA			ACM -AUDIO CONTROL MODULE		X	X	X	X		On-Demand Self-Test
AUSFORD	Australia	2003	FALCON XR8 5.0L BA			PCM -POWERTRAIN CONTROL MODULE			X	X	X		KOEO On Demand Self-Test KOER On Demand Self-Test
AUSFORD	Australia	2003	FALCON XR8 5.0L BA			ABS -ANTILOCK BRAKE MODULE		X	X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2003	FALCON XR8 5.0L BA			RCM -RESTRAINT CONTROL MODULE			X	X	X		On-Demand Self-Test
AUSFORD	Australia	2003	FALCON XR8 5.0L BA			BEM -BODY ELECTRIC MODULE		X	X	X	X		On-Demand Self-Test New BEM Installation Erase and Program Keys PCM Parameter Reset
AUSFORD	Australia	2003	FALCON XR8 5.0L BA			HIM -HVAC INITEGRAED MODULE		X	X	X	X		On-Demand Self-Test New HIM Installation
AUSFORD	Australia	2003	FALCON XR8 5.0L BA			ICM -INSTRUMENT CLUSTER MODULE		X	X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2003	FALCON XR8 5.0L BA			ACM -AUDIO CONTROL MODULE		X	X	X	X		On-Demand Self-Test
AUSFORD	Australia	2003	FUTURA 4.0L BA			PCM -POWERTRAIN CONTROL MODULE			X	X	X		KOEO On Demand Self-Test KOER On Demand Self-Test

Mark X Description Function is supported.

AUSFORD	Australia	2003	FUTURA 4.0L BA			ABS -ANTILOCK BRAKE MODULE		X	X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2003	FUTURA 4.0L BA			RCM -RESTRAINT CONTROL MODULE			X	X	X		On-Demand Self-Test
AUSFORD	Australia	2003	FUTURA 4.0L BA			BEM -BODY ELECTRIC MODULE		X	X	X	X		On-Demand Self-Test New BEM Installation Erase and Program Keys PCM Parameter Reset
AUSFORD	Australia	2003	FUTURA 4.0L BA			HIM -HVAC INTEGRATED MODULE		X	X	X	X		On-Demand Self-Test New HIM Installation
AUSFORD	Australia	2003	FUTURA 4.0L BA			ICM -INSTRUMENT CLUSTER MODULE		X	X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2003	FUTURA 4.0L BA			ACM -AUDIO CONTROL MODULE		X	X	X	X		On-Demand Self-Test
AUSFORD	Australia	2003	FAIRMONT 4.0L BA			PCM -POWERTRAIN CONTROL MODULE			X	X	X		KOEO On Demand Self-Test KOER On Demand Self-Test
AUSFORD	Australia	2003	FAIRMONT 4.0L BA			ABS -ANTILOCK BRAKE MODULE		X	X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2003	FAIRMONT 4.0L BA			RCM -RESTRAINT CONTROL MODULE			X	X	X		On-Demand Self-Test
AUSFORD	Australia	2003	FAIRMONT 4.0L BA			BEM -BODY ELECTRIC MODULE		X	X	X	X		On-Demand Self-Test New BEM Installation Erase and Program Keys PCM Parameter Reset
AUSFORD	Australia	2003	FAIRMONT 4.0L BA			HIM -HVAC INTEGRATED MODULE		X	X	X	X		On-Demand Self-Test New HIM Installation
AUSFORD	Australia	2003	FAIRMONT 4.0L BA			ICM -INSTRUMENT CLUSTER MODULE		X	X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2003	FAIRMONT 4.0L BA			ACM -AUDIO CONTROL MODULE		X	X	X	X		On-Demand Self-Test

Mark X Description Function is supported.

AUSFORD	Australia	2003	FAIRMONT GHIA 4.0L BA			PCM -POWERTRAIN CONTROL MODULE			X	X	X		KOEO On Demand Self-Test KOER On Demand Self-Test
AUSFORD	Australia	2003	FAIRMONT GHIA 4.0L BA			ABS -ANTILOCK BRAKE MODULE		X	X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2003	FAIRMONT GHIA 4.0L BA			RCM -RESTRAINT CONTROL MODULE			X	X	X		On-Demand Self-Test
AUSFORD	Australia	2003	FAIRMONT GHIA 4.0L BA			BEM -BODY ELECTRIC MODULE		X	X	X	X		On-Demand Self-Test New BEM Installation Erase and Program Keys PCM Parameter Reset
AUSFORD	Australia	2003	FAIRMONT GHIA 4.0L BA			HIM -HVAC INITEGRAED MODULE		X	X	X	X		On-Demand Self-Test New HIM Installation
AUSFORD	Australia	2003	FAIRMONT GHIA 4.0L BA			ICM -INSTRUMENT CLUSTER MODULE		X	X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2003	FAIRMONT GHIA 4.0L BA			ACM -AUDIO CONTROL MODULE		X	X	X	X		On-Demand Self-Test
AUSFORD	Australia	2003	TERRITORY 2WD			PCM -POWERTRAIN CONTROL MODULE			X	X	X		KOEO On Demand Self-Test KOER On Demand Self-Test
AUSFORD	Australia	2003	TERRITORY 2WD			ABS -ANTILOCK BRAKE MODULE			X	X	X		On-Demand Self-Test
AUSFORD	Australia	2003	TERRITORY 2WD			RCM -RESTRAINT CONTROL MODULE			X	X	X		On-Demand Self-Test
AUSFORD	Australia	2003	TERRITORY 2WD			BEM -BODY ELECTRIC MODULE		X	X	X	X		On-Demand Self-Test New BEM Installation Erase and Program Keys PCM Parameter Reset
AUSFORD	Australia	2003	TERRITORY 2WD			HIM -HVAC INITEGRAED MODULE		X	X	X	X		On-Demand Self-Test New HIM Installation
AUSFORD	Australia	2003	TERRITORY 2WD			ICM -INSTRUMENT CLUSTER MODULE		X	X	X	X	X	On-Demand Self-Test

Mark X Description Function is supported.

AUSFORD	Australia	2003	TERRITORY 2WD			ACM -AUDIO CONTROL MODULE		X	X	X	X		On-Demand Self-Test
AUSFORD	Australia	2003	TERRITORY 4WD/AWD			PCM -POWERTRAIN CONTROL MODULE			X	X	X		KOEO On Demand Self-Test KOER On Demand Self-Test
AUSFORD	Australia	2003	TERRITORY 4WD/AWD			TCM -TRANS CONTROL MODULE			X	X	X		On-Demand Self-Test
AUSFORD	Australia	2003	TERRITORY 4WD/AWD			ABS -ANTILOCK BRAKE MODULE		X	X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2003	TERRITORY 4WD/AWD			RCM -RESTRAINT CONTROL MODULE			X	X	X		On-Demand Self-Test
AUSFORD	Australia	2003	TERRITORY 4WD/AWD			BEM -BODY ELECTRIC MODULE		X	X	X	X		On-Demand Self-Test New BEM Installation Erase and Program Keys PCM Parameter Reset
AUSFORD	Australia	2003	TERRITORY 4WD/AWD			HIM -HVAC INTEGRATED MODULE		X	X	X	X		On-Demand Self-Test New HIM Installation
AUSFORD	Australia	2003	TERRITORY 4WD/AWD			ICM -INSTRUMENT CLUSTER MODULE		X	X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2003	TERRITORY 4WD/AWD			ACM -AUDIO CONTROL MODULE		X	X	X	X		On-Demand Self-Test
AUSFORD	Australia	2002	FAIRLANE/LTD 4.0L AUIII			PCM -POWERTRAIN CONTROL MODULE			X	X	X	X	KOEO On Demand Self-Test KOER On Demand Self-Test
AUSFORD	Australia	2002	FAIRLANE/LTD 4.0L AUIII			ABS -ANTILOCK BRAKE MODULE			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2002	FAIRLANE/LTD 4.0L AUIII			ACM -AUDIO CONTROL MODULE			X	X		X	On-Demand Self-Test
AUSFORD	Australia	2002	FAIRLANE/LTD 4.0L AUIII			BEM -BODY ELECTRIC MODULE				X	X	X	Erase And Program Keys Parameter Reset
AUSFORD	Australia	2002	FAIRLANE/LTD 4.0L AUIII			RCM -RESTRAINT CONTROL MODULE			X	X	X	X	On-Demand Self-Test

Mark X Description Function is supported.

AUSFORD	Australia	2002	FAIRLANE/LTD 5.0L AUIII			PCM -POWERTRAIN CONTROL MODULE			X	X	X	X	KOEO On Demand Self-Test KOER On Demand Self-Test
AUSFORD	Australia	2002	FAIRLANE/LTD 5.0L AUIII			ABS -ANTILOCK BRAKE MODULE			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2002	FAIRLANE/LTD 5.0L AUIII			ACM -AUDIO CONTROL MODULE			X	X		X	On-Demand Self-Test
AUSFORD	Australia	2002	FAIRLANE/LTD 5.0L AUIII			BEM -BODY ELECTRIC MODULE				X	X	X	Erase And Program Keys Parameter Reset
AUSFORD	Australia	2002	FAIRLANE/LTD 5.0L AUIII			RCM -RESTRAINT CONTROL MODULE			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2002	FAIRMONT 4.0L AUIII			PCM -POWERTRAIN CONTROL MODULE			X	X	X	X	KOEO On Demand Self-Test KOER On Demand Self-Test
AUSFORD	Australia	2002	FAIRMONT 4.0L AUIII			ABS -ANTILOCK BRAKE MODULE			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2002	FAIRMONT 4.0L AUIII			ACM -AUDIO CONTROL MODULE			X	X		X	On-Demand Self-Test
AUSFORD	Australia	2002	FAIRMONT 4.0L AUIII			BEM -BODY ELECTRIC MODULE				X	X	X	Erase And Program Keys Parameter Reset
AUSFORD	Australia	2002	FAIRMONT 4.0L AUIII			RCM -RESTRAINT CONTROL MODULE			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2002	FAIRMONT 5.0L AUIII			PCM -POWERTRAIN CONTROL MODULE			X	X	X	X	KOEO On Demand Self-Test KOER On Demand Self-Test
AUSFORD	Australia	2002	FAIRMONT 5.0L AUIII			ABS -ANTILOCK BRAKE MODULE			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2002	FAIRMONT 5.0L AUIII			ACM -AUDIO CONTROL MODULE			X	X		X	On-Demand Self-Test
AUSFORD	Australia	2002	FAIRMONT 5.0L AUIII			BEM -BODY ELECTRIC MODULE				X	X	X	Erase And Program Keys Parameter Reset

Mark X Description Function is supported.

AUSFORD	Australia	2002	FAIRMONT 5.0L AUIII			RCM -RESTRAINT CONTROL MODULE			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2002	FALCON FORTE 4.0L AUIII			PCM -POWERTRAIN CONTROL MODULE			X	X	X	X	KOEO On Demand Self-Test KOER On Demand Self-Test
AUSFORD	Australia	2002	FALCON FORTE 4.0L AUIII			ABS -ANTILOCK BRAKE MODULE			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2002	FALCON FORTE 4.0L AUIII			ACM -AUDIO CONTROL MODULE			X	X		X	On-Demand Self-Test
AUSFORD	Australia	2002	FALCON FORTE 4.0L AUIII			BEM -BODY ELECTRIC MODULE				X	X	X	Erase And Program Keys Parameter Reset
AUSFORD	Australia	2002	FALCON FORTE 4.0L AUIII			RCM -RESTRAINT CONTROL MODULE			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2002	FALCON FUTURA 4.0L AUIII			PCM -POWERTRAIN CONTROL MODULE			X	X	X	X	KOEO On Demand Self-Test KOER On Demand Self-Test
AUSFORD	Australia	2002	FALCON FUTURA 4.0L AUIII			ABS -ANTILOCK BRAKE MODULE			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2002	FALCON FUTURA 4.0L AUIII			ACM -AUDIO CONTROL MODULE			X	X		X	On-Demand Self-Test
AUSFORD	Australia	2002	FALCON FUTURA 4.0L AUIII			BEM -BODY ELECTRIC MODULE				X	X	X	Erase And Program Keys Parameter Reset
AUSFORD	Australia	2002	FALCON FUTURA 4.0L AUIII			RCM -RESTRAINT CONTROL MODULE			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2002	FALCON XR 4.0L AUIII			PCM -POWERTRAIN CONTROL MODULE			X	X	X	X	KOEO On Demand Self-Test KOER On Demand Self-Test
AUSFORD	Australia	2002	FALCON XR 4.0L AUIII			ABS -ANTILOCK BRAKE MODULE			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2002	FALCON XR 4.0L AUIII			ACM -AUDIO CONTROL MODULE			X	X		X	On-Demand Self-Test

Mark X Description Function is supported.

AUSFORD	Australia	2002	FALCON XR 4.0L AUIII			BEM -BODY ELECTRIC MODULE				X	X	X	Erase And Program Keys Parameter Reset
AUSFORD	Australia	2002	FALCON XR 4.0L AUIII			RCM -RESTRAINT CONTROL MODULE			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2002	FALCON XR 5.0L AUIII			PCM -POWERTRAIN CONTROL MODULE			X	X	X	X	KOEO On Demand Self-Test KOER On Demand Self-Test
AUSFORD	Australia	2002	FALCON XR 5.0L AUIII			ABS -ANTILOCK BRAKE MODULE			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2002	FALCON XR 5.0L AUIII			ACM -AUDIO CONTROL MODULE			X	X		X	On-Demand Self-Test
AUSFORD	Australia	2002	FALCON XR 5.0L AUIII			BEM -BODY ELECTRIC MODULE				X	X	X	Erase And Program Keys Parameter Reset
AUSFORD	Australia	2002	FALCON XR 5.0L AUIII			RCM -RESTRAINT CONTROL MODULE			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2002	TRANSIT 2.5L DIESEL			ABS -ANTILOCK BRAKE MODULE			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2002	TRANSIT 2.5L DIESEL			CSM -CENTRAL SECURITY MODULE			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2002	TRANSIT 2.5L DIESEL			PAM -PARK AID MODULE			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2002	TRANSIT 2.5L DIESEL			RASM-REAR AIR SUSP. MODULE			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2002	TRANSIT 2.5L DIESEL			RCM -RESTRAINT CONTROL MODULE			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2001	FAIRLANE/LTD 4.0L AUII			PCM -POWERTRAIN CONTROL MODULE			X	X	X	X	KOEO On Demand Self-Test KOER On Demand Self-Test
AUSFORD	Australia	2001	FAIRLANE/LTD 4.0L AUII			ABS -ANTILOCK BRAKE MODULE			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2001	FAIRLANE/LTD 4.0L AUII			ACM -AUDIO CONTROL MODULE			X	X		X	On-Demand Self-Test

Mark X Description Function is supported.

AUSFORD	Australia	2001	FAIRLANE/LTD 4.0L AUII			BEM -BODY ELECTRIC MODULE				X	X	X	Erase And Program Keys Parameter Reset
AUSFORD	Australia	2001	FAIRLANE/LTD 4.0L AUII			RCM -RESTRAINT CONTROL MODULE			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2001	FAIRLANE/LTD 5.0L AUII			PCM -POWERTRAIN CONTROL MODULE			X	X	X	X	KOEO On Demand Self-Test KOER On Demand Self-Test
AUSFORD	Australia	2001	FAIRLANE/LTD 5.0L AUII			ABS -ANTILOCK BRAKE MODULE			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2001	FAIRLANE/LTD 5.0L AUII			ACM -AUDIO CONTROL MODULE			X	X		X	On-Demand Self-Test
AUSFORD	Australia	2001	FAIRLANE/LTD 5.0L AUII			BEM -BODY ELECTRIC MODULE				X	X	X	Erase And Program Keys Parameter Reset
AUSFORD	Australia	2001	FAIRLANE/LTD 5.0L AUII			RCM -RESTRAINT CONTROL MODULE			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2001	FAIRMONT 4.0L AUII			PCM -POWERTRAIN CONTROL MODULE			X	X	X	X	KOEO On Demand Self-Test KOER On Demand Self-Test
AUSFORD	Australia	2001	FAIRMONT 4.0L AUII			ABS -ANTILOCK BRAKE MODULE			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2001	FAIRMONT 4.0L AUII			ACM -AUDIO CONTROL MODULE			X	X		X	On-Demand Self-Test
AUSFORD	Australia	2001	FAIRMONT 4.0L AUII			BEM -BODY ELECTRIC MODULE				X	X	X	Erase And Program Keys Parameter Reset
AUSFORD	Australia	2001	FAIRMONT 4.0L AUII			RCM -RESTRAINT CONTROL MODULE			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2001	FAIRMONT 5.0L AUII			PCM -POWERTRAIN CONTROL MODULE			X	X	X	X	KOEO On Demand Self-Test KOER On Demand Self-Test
AUSFORD	Australia	2001	FAIRMONT 5.0L AUII			ABS -ANTILOCK BRAKE MODULE			X	X	X	X	On-Demand Self-Test

Mark X Description Function is supported.

AUSFORD	Australia	2001	FAIRMONT 5.0L AUII			ACM -AUDIO CONTROL MODULE			X	X		X	On-Demand Self-Test
AUSFORD	Australia	2001	FAIRMONT 5.0L AUII			BEM -BODY ELECTRIC MODULE				X	X	X	Erase And Program Keys Parameter Reset
AUSFORD	Australia	2001	FAIRMONT 5.0L AUII			RCM -RESTRAINT CONTROL MODULE			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2001	FALCON FORTE 4.0L AUII			PCM -POWERTRAIN CONTROL MODULE			X	X	X	X	KOEO On Demand Self-Test KOER On Demand Self-Test
AUSFORD	Australia	2001	FALCON FORTE 4.0L AUII			ABS -ANTILOCK BRAKE MODULE			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2001	FALCON FORTE 4.0L AUII			ACM -AUDIO CONTROL MODULE			X	X		X	On-Demand Self-Test
AUSFORD	Australia	2001	FALCON FORTE 4.0L AUII			BEM -BODY ELECTRIC MODULE				X	X	X	Erase And Program Keys Parameter Reset
AUSFORD	Australia	2001	FALCON FORTE 4.0L AUII			RCM -RESTRAINT CONTROL MODULE			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2001	FALCON FUTURA 4.0L AUII			PCM -POWERTRAIN CONTROL MODULE			X	X	X	X	KOEO On Demand Self-Test KOER On Demand Self-Test
AUSFORD	Australia	2001	FALCON FUTURA 4.0L AUII			ABS -ANTILOCK BRAKE MODULE			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2001	FALCON FUTURA 4.0L AUII			ACM -AUDIO CONTROL MODULE			X	X		X	On-Demand Self-Test
AUSFORD	Australia	2001	FALCON FUTURA 4.0L AUII			BEM -BODY ELECTRIC MODULE				X	X	X	Erase And Program Keys Parameter Reset
AUSFORD	Australia	2001	FALCON FUTURA 4.0L AUII			RCM -RESTRAINT CONTROL MODULE			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2001	FALCON XR 4.0L AUII			PCM -POWERTRAIN CONTROL MODULE			X	X	X	X	KOEO On Demand Self-Test KOER On Demand Self-Test

Mark X Description Function is supported.

AUSFORD	Australia	2001	FALCON XR 4.0L AUII			ABS -ANTILOCK BRAKE MODULE			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2001	FALCON XR 4.0L AUII			ACM -AUDIO CONTROL MODULE			X	X		X	On-Demand Self-Test
AUSFORD	Australia	2001	FALCON XR 4.0L AUII			BEM -BODY ELECTRIC MODULE				X	X	X	Erase And Program Keys Parameter Reset
AUSFORD	Australia	2001	FALCON XR 4.0L AUII			RCM -RESTRAINT CONTROL MODULE			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2001	FALCON XR 5.0L AUII			PCM -POWERTRAIN CONTROL MODULE			X	X	X	X	KOEO On Demand Self-Test KOER On Demand Self-Test
AUSFORD	Australia	2001	FALCON XR 5.0L AUII			ABS -ANTILOCK BRAKE MODULE			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2001	FALCON XR 5.0L AUII			ACM -AUDIO CONTROL MODULE			X	X		X	On-Demand Self-Test
AUSFORD	Australia	2001	FALCON XR 5.0L AUII			BEM -BODY ELECTRIC MODULE				X	X	X	Erase And Program Keys Parameter Reset
AUSFORD	Australia	2001	FALCON XR 5.0L AUII			RCM -RESTRAINT CONTROL MODULE			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2001	TRANSIT 2.5L DIESEL			ABS -ANTILOCK BRAKE MODULE			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2001	TRANSIT 2.5L DIESEL			CSM -CENTRAL SECURITY MODULE			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2001	TRANSIT 2.5L DIESEL			PAM -PARK AID MODULE			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2001	TRANSIT 2.5L DIESEL			RASM-REAR AIR SUSP. MODULE			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2001	TRANSIT 2.5L DIESEL			RCM -RESTRAINT CONTROL MODULE			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2000	COUGAR 2.5L			ABS -ANTILOCK BRAKE MODULE			X	X	X	X	On-Demand Self-Test

Mark X Description Function is supported.

AUSFORD	Australia	2000	COUGAR 2.5L			CSM -CENTRAL SECURITY MODULE			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2000	COUGAR 2.5L			ECS -ELECTRIC CRASH SENSOR(OR IABM)			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2000	COUGAR 2.5L			HEC -HYBRID ELECTRIC CLUSTER			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2000	ESCORT 1.8L			ABS -ANTILOCK BRAKE MODULE			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2000	ESCORT 1.8L			HEC -HYBRID ELECTRIC CLUSTER			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2000	ESCORT 1.8L DIESEL			ABS -ANTILOCK BRAKE MODULE			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2000	ESCORT 1.8L DIESEL			HEC -HYBRID ELECTRIC CLUSTER			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2000	EXPLORER 4.0L			ABS -ANTILOCK BRAKE MODULE			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2000	EXPLORER 4.0L			ARC -AUTO RIDE CONTROL MODULE			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2000	EXPLORER 4.0L			GEM -GENERIC ELECTRIC MODULE(OR CTM)			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2000	EXPLORER 4.0L			DSM -DRVR SEAT MODULE			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2000	EXPLORER 4.0L			RAP -REMOTE ANTITHEFT MODULE			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2000	EXPLORER 4.0L			RCM -RESTRAINT CONTROL MODULE			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2000	FAIRLANE/LTD 4.0L AUII			PCM -POWERTRAIN CONTROL MODULE			X	X	X	X	KOEO On Demand Self-Test KOER On Demand Self-Test
AUSFORD	Australia	2000	FAIRLANE/LTD 4.0L AUII			ABS -ANTILOCK BRAKE MODULE			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2000	FAIRLANE/LTD 4.0L AUII			ACM -AUDIO CONTROL MODULE			X	X		X	On-Demand Self-Test

Mark X Description Function is supported.

AUSFORD	Australia	2000	FAIRLANE/LTD 4.0L AUII			BEM -BODY ELECTRIC MODULE				X	X	X	Erase And Program Keys Parameter Reset
AUSFORD	Australia	2000	FAIRLANE/LTD 4.0L AUII			RCM -RESTRAINT CONTROL MODULE			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2000	FAIRLANE/LTD 5.0L AUII			PCM -POWERTRAIN CONTROL MODULE			X	X	X	X	KOEO On Demand Self-Test KOER On Demand Self-Test
AUSFORD	Australia	2000	FAIRLANE/LTD 5.0L AUII			ABS -ANTILOCK BRAKE MODULE			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2000	FAIRLANE/LTD 5.0L AUII			ACM -AUDIO CONTROL MODULE			X	X		X	On-Demand Self-Test
AUSFORD	Australia	2000	FAIRLANE/LTD 5.0L AUII			BEM -BODY ELECTRIC MODULE				X	X	X	Erase And Program Keys Parameter Reset
AUSFORD	Australia	2000	FAIRLANE/LTD 5.0L AUII			RCM -RESTRAINT CONTROL MODULE			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2000	FAIRMONT 4.0L AUII			PCM -POWERTRAIN CONTROL MODULE			X	X	X	X	KOEO On Demand Self-Test KOER On Demand Self-Test
AUSFORD	Australia	2000	FAIRMONT 4.0L AUII			ABS -ANTILOCK BRAKE MODULE			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2000	FAIRMONT 4.0L AUII			ACM -AUDIO CONTROL MODULE			X	X		X	On-Demand Self-Test
AUSFORD	Australia	2000	FAIRMONT 4.0L AUII			BEM -BODY ELECTRIC MODULE				X	X	X	Erase And Program Keys Parameter Reset
AUSFORD	Australia	2000	FAIRMONT 4.0L AUII			RCM -RESTRAINT CONTROL MODULE			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2000	FAIRMONT 5.0L AUII			PCM -POWERTRAIN CONTROL MODULE			X	X	X	X	KOEO On Demand Self-Test KOER On Demand Self-Test
AUSFORD	Australia	2000	FAIRMONT 5.0L AUII			ABS -ANTILOCK BRAKE MODULE			X	X	X	X	On-Demand Self-Test

Mark X Description Function is supported.

AUSFORD	Australia	2000	FAIRMONT 5.0L AUII			ACM -AUDIO CONTROL MODULE			X	X		X	On-Demand Self-Test
AUSFORD	Australia	2000	FAIRMONT 5.0L AUII			BEM -BODY ELECTRIC MODULE				X	X	X	Erase And Program Keys Parameter Reset
AUSFORD	Australia	2000	FAIRMONT 5.0L AUII			RCM -RESTRAINT CONTROL MODULE			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2000	FALCON FORTE 4.0L AUII			PCM -POWERTRAIN CONTROL MODULE			X	X	X	X	KOEO On Demand Self-Test KOER On Demand Self-Test
AUSFORD	Australia	2000	FALCON FORTE 4.0L AUII			ABS -ANTILOCK BRAKE MODULE			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2000	FALCON FORTE 4.0L AUII			ACM -AUDIO CONTROL MODULE			X	X		X	On-Demand Self-Test
AUSFORD	Australia	2000	FALCON FORTE 4.0L AUII			BEM -BODY ELECTRIC MODULE				X	X	X	Erase And Program Keys Parameter Reset
AUSFORD	Australia	2000	FALCON FORTE 4.0L AUII			RCM -RESTRAINT CONTROL MODULE			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2000	FALCON FUTURA 4.0L AUII			PCM -POWERTRAIN CONTROL MODULE			X	X	X	X	KOEO On Demand Self-Test KOER On Demand Self-Test
AUSFORD	Australia	2000	FALCON FUTURA 4.0L AUII			ABS -ANTILOCK BRAKE MODULE			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2000	FALCON FUTURA 4.0L AUII			ACM -AUDIO CONTROL MODULE			X	X		X	On-Demand Self-Test
AUSFORD	Australia	2000	FALCON FUTURA 4.0L AUII			BEM -BODY ELECTRIC MODULE				X	X	X	Erase And Program Keys Parameter Reset
AUSFORD	Australia	2000	FALCON FUTURA 4.0L AUII			RCM -RESTRAINT CONTROL MODULE			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2000	FALCON XR 4.0L AUII			PCM -POWERTRAIN CONTROL MODULE			X	X	X	X	KOEO On Demand Self-Test KOER On Demand Self-Test

Mark X Description Function is supported.

AUSFORD	Australia	2000	FALCON XR 4.0L AUII			ABS -ANTILOCK BRAKE MODULE			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2000	FALCON XR 4.0L AUII			ACM -AUDIO CONTROL MODULE			X	X		X	On-Demand Self-Test
AUSFORD	Australia	2000	FALCON XR 4.0L AUII			BEM -BODY ELECTRIC MODULE				X	X	X	Erase And Program Keys Parameter Reset
AUSFORD	Australia	2000	FALCON XR 4.0L AUII			RCM -RESTRAINT CONTROL MODULE			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2000	FALCON XR 5.0L AUII			PCM -POWERTRAIN CONTROL MODULE			X	X	X	X	KOEO On Demand Self-Test KOER On Demand Self-Test
AUSFORD	Australia	2000	FALCON XR 5.0L AUII			ABS -ANTILOCK BRAKE MODULE			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2000	FALCON XR 5.0L AUII			ACM -AUDIO CONTROL MODULE			X	X		X	On-Demand Self-Test
AUSFORD	Australia	2000	FALCON XR 5.0L AUII			BEM -BODY ELECTRIC MODULE				X	X	X	Erase And Program Keys Parameter Reset
AUSFORD	Australia	2000	FALCON XR 5.0L AUII			RCM -RESTRAINT CONTROL MODULE			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2000	KA 1.3L			ABS -ANTILOCK BRAKE MODULE			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2000	KA 1.3L			ECS -ELECTRIC CRASH SENSOR(OR IABM)			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2000	MONDEO 1.8L HC			ABS -ANTILOCK BRAKE MODULE			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2000	MONDEO 1.8L HC			CSM -CENTRAL SECURITY MODULE			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2000	MONDEO 1.8L DIESEL			ABS -ANTILOCK BRAKE MODULE			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2000	MONDEO 1.8L DIESEL			CSM -CENTRAL SECURITY MODULE			X	X	X	X	On-Demand Self-Test

Mark X Description Function is supported.

AUSFORD	Australia	2000	MONDEO 2.0L HC			ABS -ANTILOCK BRAKE MODULE			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2000	MONDEO 2.0L HC			CSM -CENTRAL SECURITY MODULE			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2000	MONDEO 2.5L HC			ABS -ANTILOCK BRAKE MODULE			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2000	MONDEO 2.5L HC			CSM -CENTRAL SECURITY MODULE			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2000	MUSTANG 4.6L			ABS -ANTILOCK BRAKE MODULE			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2000	MUSTANG 4.6L			GEM -GENERIC ELECTRIC MODULE(OR CTM)			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2000	MUSTANG 4.6L			RCM -RESTRAINT CONTROL MODULE			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2000	MUSTANG 4.6L 2V/4V			ABS -ANTILOCK BRAKE MODULE			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2000	MUSTANG 4.6L 2V/4V			GEM -GENERIC ELECTRIC MODULE(OR CTM)			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2000	MUSTANG 4.6L 2V/4V			RCM -RESTRAINT CONTROL MODULE			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2000	TRANSIT 2.0L			ABS -ANTILOCK BRAKE MODULE			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	2000	TRANSIT 2.5L DIESEL			ABS -ANTILOCK BRAKE MODULE			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	1999	COUGAR 2.0L			ABS -ANTILOCK BRAKE MODULE			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	1999	COUGAR 2.0L			ECS -ELECTRIC CRASH SENSOR(OR IABM)			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	1999	COUGAR 2.0L			HEC -HYBRID ELECTRIC CLUSTER			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	1999	COUGAR 2.5L			ABS -ANTILOCK BRAKE MODULE			X	X	X	X	On-Demand Self-Test

Mark X Description Function is supported.

AUSFORD	Australia	1999	COUGAR 2.5L			ECS -ELECTRIC CRASH SENSOR(OR IABM)			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	1999	COUGAR 2.5L			HEC -HYBRID ELECTRIC CLUSTER			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	1999	ESCORT 1.8L			ABS -ANTILOCK BRAKE MODULE			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	1999	ESCORT 1.8 DIESEL			ABS -ANTILOCK BRAKE MODULE			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	1999	EXPLORER 4.0L			ABS -ANTILOCK BRAKE MODULE			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	1999	EXPLORER 4.0L			ARC -AUTO RIDE CONTROL MODULE			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	1999	EXPLORER 4.0L			GEM -GENERIC ELECTRIC MODULE(OR CTM)			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	1999	EXPLORER 4.0L			DSM -DRVR SEAT MODULE			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	1999	EXPLORER 4.0L			PAM -PARK AID MODULE			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	1999	EXPLORER 4.0L			RAP -REMOTE ANTITHEFT MODULE			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	1999	EXPLORER 4.0L			RCM -RESTRAINT CONTROL MODULE			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	1999	FAIRLANE/LTD 4.0L AU			PCM -POWERTRAIN CONTROL MODULE			X	X	X	X	KOEO On Demand Self-Test KOER On Demand Self-Test
AUSFORD	Australia	1999	FAIRLANE/LTD 4.0L AU			ABS -ANTILOCK BRAKE MODULE			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	1999	FAIRLANE/LTD 4.0L AU			IABM -INTG AIR BAG MONITOR			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	1999	FAIRLANE/LTD 5.0L AU			PCM -POWERTRAIN CONTROL MODULE			X	X	X	X	KOEO On Demand Self-Test KOER On Demand Self-Test

Mark X Description Function is supported.

AUSFORD	Australia	1999	FAIRLANE/LTD 5.0L AU			ABS -ANTILOCK BRAKE MODULE			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	1999	FAIRLANE/LTD 5.0L AU			IABM -INTG AIR BAG MONITOR			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	1999	FAIRMONT 4.0L AU			PCM -POWERTRAIN CONTROL MODULE			X	X	X	X	KOEO On Demand Self-Test KOER On Demand Self-Test
AUSFORD	Australia	1999	FAIRMONT 4.0L AU			ABS -ANTILOCK BRAKE MODULE			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	1999	FAIRMONT 4.0L AU			IABM -INTG AIR BAG MONITOR			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	1999	FAIRMONT 5.0L AU			PCM -POWERTRAIN CONTROL MODULE			X	X	X	X	KOEO On Demand Self-Test KOER On Demand Self-Test
AUSFORD	Australia	1999	FAIRMONT 5.0L AU			ABS -ANTILOCK BRAKE MODULE			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	1999	FAIRMONT 5.0L AU			IABM -INTG AIR BAG MONITOR			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	1999	FALCON FUTRA 4.0L AU			PCM -POWERTRAIN CONTROL MODULE			X	X	X	X	KOEO On Demand Self-Test KOER On Demand Self-Test
AUSFORD	Australia	1999	FALCON FUTRA 4.0L AU			ABS -ANTILOCK BRAKE MODULE			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	1999	FALCON FUTRA 4.0L AU			IABM -INTG AIR BAG MONITOR			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	1999	FALCON FUTRA 5.0L AU			PCM -POWERTRAIN CONTROL MODULE			X	X	X	X	KOEO On Demand Self-Test KOER On Demand Self-Test
AUSFORD	Australia	1999	FALCON FUTRA 5.0L AU			ABS -ANTILOCK BRAKE MODULE			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	1999	FALCON FUTRA 5.0L AU			IABM -INTG AIR BAG MONITOR			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	1999	FALCON FORTE 4.0L AU			PCM -POWERTRAIN CONTROL MODULE			X	X	X	X	KOEO On Demand Self-Test KOER On Demand Self-Test
AUSFORD	Australia	1999	FALCON FORTE 4.0L AU			ABS -ANTILOCK BRAKE MODULE			X	X	X	X	On-Demand Self-Test

Mark X Description Function is supported.

AUSFORD	Australia	1999	FALCON FORTE 4.0L AU			IABM -INTG AIR BAG MONITOR			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	1999	FALCON FORTE 5.0L AU			PCM -POWERTRAIN CONTROL MODULE			X	X	X	X	KOEO On Demand Self-Test KOER On Demand Self-Test
AUSFORD	Australia	1999	FALCON FORTE 5.0L AU			ABS -ANTILOCK BRAKE MODULE			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	1999	FALCON FORTE 5.0L AU			IABM -INTG AIR BAG MONITOR			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	1999	KA 1.3L			ABS -ANTILOCK BRAKE MODULE			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	1999	MONDEO 1.8L HC			ABS -ANTILOCK BRAKE MODULE			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	1999	MONDEO 1.8L HC			CSM -CENTRAL SECURITY MODULE			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	1999	MONDEO 1.8L DIESEL			ABS -ANTILOCK BRAKE MODULE			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	1999	MONDEO 1.8L DIESEL			CSM -CENTRAL SECURITY MODULE			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	1999	MONDEO 2.0L HC HTX			ABS -ANTILOCK BRAKE MODULE			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	1999	MONDEO 2.0L HC HTX			CSM -CENTRAL SECURITY MODULE			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	1999	MONDEO 2.0L HC MTX			ABS -ANTILOCK BRAKE MODULE			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	1999	MONDEO 2.0L HC MTX			CSM -CENTRAL SECURITY MODULE			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	1999	MONDEO 2.5L HC			ABS -ANTILOCK BRAKE MODULE			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	1999	MONDEO 2.5L HC			CSM -CENTRAL SECURITY MODULE			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	1999	TRANSIT 2.0L			ABS -ANTILOCK BRAKE MODULE			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	1999	TRANSIT 2.5L DIESEL			ABS -ANTILOCK BRAKE MODULE			X	X	X	X	On-Demand Self-Test

Mark X Description Function is supported.

AUSFORD	Australia	1998	ESCORT 1.6L ATX			ABS -ANTILOCK BRAKE MODULE			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	1998	ESCORT 1.8L			ABS -ANTILOCK BRAKE MODULE			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	1998	ESCORT 1.8L DIESEL			ABS -ANTILOCK BRAKE MODULE			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	1998	EXPLORER 4.0L			ABS -ANTILOCK BRAKE MODULE			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	1998	EXPLORER 4.0L			ARC -AUTO RIDE CONTROL MODULE			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	1998	EXPLORER 4.0L			GEM -GENERIC ELECTRIC MODULE(OR CTM)			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	1998	EXPLORER 4.0L			DSM -DRVR SEAT MODULE			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	1998	EXPLORER 4.0L			IABM -INTG AIR BAG MONITOR			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	1998	EXPLORER 4.0L			RAP -REMOTE ANTITHEFT MODULE			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	1998	MONDEO 1.8L HC			ABS -ANTILOCK BRAKE MODULE			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	1998	MONDEO 1.8L HC			CSM -CENTRAL SECURITY MODULE			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	1998	MONDEO 1.8L DIESEL			ABS -ANTILOCK BRAKE MODULE			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	1998	MONDEO 1.8L DIESEL			CSM -CENTRAL SECURITY MODULE			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	1998	MONDEO 2.0L HC ATX			ABS -ANTILOCK BRAKE MODULE			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	1998	MONDEO 2.0L HC ATX			CSM -CENTRAL SECURITY MODULE			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	1998	MONDEO 2.0L HC MTX			ABS -ANTILOCK BRAKE MODULE			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	1998	MONDEO 2.0L HC MTX			CSM -CENTRAL SECURITY MODULE			X	X	X	X	On-Demand Self-Test

Mark X Description Function is supported.

AUSFORD	Australia	1998	MONDEO 2.5L HC			ABS -ANTILOCK BRAKE MODULE			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	1998	MONDEO 2.5L HC			CSM -CENTRAL SECURITY MODULE			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	1998	TAURUS 3.0L 4V			ABS -ANTILOCK BRAKE MODULE			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	1998	TAURUS 3.0L 4V			GEM -GENERIC ELECTRIC MODULE(OR CTM)			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	1998	TAURUS 3.0L 4V			IABM -INTG AIR BAG MONITOR			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	1998	TAURUS 3.0L 4V			RAP -REMOTE ANTITHEFT MODULE			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	1998	TRANSIT 2.0L			ABS -ANTILOCK BRAKE MODULE			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	1998	TRANSIT 2.5L DIESEL			ABS -ANTILOCK BRAKE MODULE			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	1997	ESCORT 1.4L			ABS -ANTILOCK BRAKE MODULE			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	1997	ESCORT 1.6L MTX			ABS -ANTILOCK BRAKE MODULE			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	1997	ESCORT 1.8L			ABS -ANTILOCK BRAKE MODULE			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	1997	ESCORT 1.8L DIESEL			ABS -ANTILOCK BRAKE MODULE			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	1997	EXPLORER 4.0L ATX			ARC -AUTO RIDE CONTROL MODULE			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	1997	EXPLORER 4.0L ATX			GEM -GENERIC ELECTRIC MODULE(OR CTM)			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	1997	EXPLORER 4.0L ATX			IABM -INTG AIR BAG MONITOR			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	1997	EXPLORER 4.0L ATX			RAP -REMOTE ANTITHEFT MODULE			X	X	X	X	On-Demand Self-Test

Mark X Description Function is supported.

AUSFORD	Australia	1997	EXPLORER 4.0L MTX			ARC -AUTO RIDE CONTROL MODULE			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	1997	EXPLORER 4.0L MTX			GEM -GENERIC ELECTRIC MODULE(OR CTM)			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	1997	EXPLORER 4.0L MTX			IABM -INTG AIR BAG MONITOR			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	1997	EXPLORER 4.0L MTX			RAP -REMOTE ANTITHEFT MODULE			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	1997	TAURUS 3.0L 4V			ABS -ANTILOCK BRAKE MODULE			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	1997	TAURUS 3.0L 4V			GEM -GENERIC ELECTRIC MODULE(OR CTM)			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	1997	TAURUS 3.0L 4V			IABM -INTG AIR BAG MONITOR			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	1997	TAURUS 3.0L 4V			RAP -REMOTE ANTITHEFT MODULE			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	1997	TRANSIT 2.0L			ABS -ANTILOCK BRAKE MODULE			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	1997	TRANSIT 2.5L DIESEL			ABS -ANTILOCK BRAKE MODULE			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	1996	TAURUS 3.0L 4V			ABS -ANTILOCK BRAKE MODULE			X	X	X	X	On-Demand Self-Test
AUSFORD	Australia	1996	TAURUS 3.0L 4V			GEM -GENERIC ELECTRIC MODULE(OR CTM)			X	X	X	X	On-Demand Self-Test

Basic Function

Automaker	Region	Year	Model	Vehicle Type	ECU Type	System	ECU Supplier	Sys. Info.	Read Code	Clear Code	Data Stream	Actuations
-----------	--------	------	-------	--------------	----------	--------	--------------	------------	-----------	------------	-------------	------------

Mark X Description Function is supported.

Automaker	Region	Year	Model	Vehicle Type	ECU Type	System	ECU Supplier	Sys. Info.	Read Code	Clear Code	Data Stream	Actuations
AUSFORD	Australia	2011	Falcon Forte S/Futura/XR/XT 5.0L FG			PCM -POWERTRAIN CONTROL MODULE			X	X	X	
AUSFORD	Australia	2011	Falcon Forte S/Futura/XR/XT 5.0L FG			TCM -TRANS CONTROL MODULE			X	X	X	
AUSFORD	Australia	2011	Falcon Forte S/Futura/XR/XT 5.0L FG			ABS -ANTILOCK BRAKE MODULE			X	X	X	
AUSFORD	Australia	2011	Falcon Forte S/Futura/XR/XT 5.0L FG			RCM -RESTRAINT CONTROL MODULE			X	X	X	
AUSFORD	Australia	2011	Falcon Forte S/Futura/XR/XT 5.0L FG			BEM -BODY ELECTRIC MODULE			X	X	X	
AUSFORD	Australia	2011	Falcon Forte S/Futura/XR/XT 5.0L FG			ICM -INSTRUMENT CLUSTER MODULE			X	X	X	
AUSFORD	Australia	2011	Falcon Forte S/Futura/XR/XT 5.0L FG			HIM -HVAC INTEGRATED MODULE			X	X	X	
AUSFORD	Australia	2011	Falcon Forte S/Futura/XR/XT 5.0L FG			ACM -AUDIO CONTROL MODULE			X	X	X	
AUSFORD	Australia	2011	Falcon Forte S/Futura/XR/XT 5.0L FG			AIM -AUDIO INTERFACE MODULE			X	X	X	
AUSFORD	Australia	2011	Falcon Forte S/Futura/XR/XT 5.0L FG			FDIM -FRONT DISPLAY INTERFACE MODULE			X	X	X	
AUSFORD	Australia	2011	Falcon Forte S/Futura/XR/XT 5.0L FG			BPM -BLUETOOTH PHONE MODULE			X	X	X	
AUSFORD	Australia	2011	Falcon Forte S/Futura/XR/XT 5.0L FG			PAM -PARK AID MODULE			X	X	X	
AUSFORD	Australia	2011	Ranger 2.5L(DURATEC-HE/I4)			PCM -POWERTRAIN CONTROL MODULE			*	*	*	
AUSFORD	Australia	2011	Ranger 2.5L(DURATEC-HE/I4)			ABS -ANTILOCK BRAKE MODULE			*	*	*	
AUSFORD	Australia	2011	Ranger 2.5L(DURATEC-HE/I4)			RCM -RESTRAINT CONTROL MODULE			*	*	*	
AUSFORD	Australia	2011	Ranger 2.5L(DURATEC-HE/I4)			BCM -Body Control Module			*	*	*	

Mark X Description Function is supported.

AUSFORD	Australia	2011	Ranger 2.5L(DURATEC-HE/I4)			IPC -INSTRUMENT PANEL CONTROL MODULE			*	*	*	
AUSFORD	Australia	2011	Ranger 2.5L(DURATEC-HE/I4)			PAM -PARK AID MODULE			*	*	*	
AUSFORD	Australia	2011	Ranger 2.5L(DURATEC-HE/I4)			ACM -AUDIO CONTROL MODULE			*	*	*	
AUSFORD	Australia	2011	Ranger 2.5L(DURATEC-HE/I4)			DDM -Driver's Door Module			*	*	*	
AUSFORD	Australia	2011	Ranger 2.5L(DURATEC-HE/I4)			FCDIM -Front Control/Dispaly Interface Module			*	*	*	
AUSFORD	Australia	2011	Ranger 2.5L(DURATEC-HE/I4)			HVAC -Heating Ventilation Air Conditioning			*	*	*	
AUSFORD	Australia	2011	Ranger 2.5L(DURATEC-HE/I4)			PDM -Passenger's Door Module			*	*	*	
AUSFORD	Australia	2011	Ranger 2.5L(DURATEC-HE/I4)			SRM -Speech Recognition Module			*	*	*	
AUSFORD	Australia	2011	Ranger 2.5L(DURATEC-HE/I4)			TRM -Trailer Module			*	*	*	
AUSFORD	Australia	2011	Ranger 3.2L(Duratorq-Turbo Diesel Common Rail Injection)			PCM -POWERTRAIN CONTROL MODULE			*	*	*	
AUSFORD	Australia	2011	Ranger 3.2L(Duratorq-Turbo Diesel Common Rail Injection)			ABS -ANTILOCK BRAKE MODULE			*	*	*	
AUSFORD	Australia	2011	Ranger 3.2L(Duratorq-Turbo Diesel Common Rail Injection)			RCM -RESTRAINT CONTROL MODULE			*	*	*	
AUSFORD	Australia	2011	Ranger 3.2L(Duratorq-Turbo Diesel Common Rail Injection)			TCM -TRANS CONTROL MODULE			*	*	*	
AUSFORD	Australia	2011	Ranger 3.2L(Duratorq-Turbo Diesel Common Rail Injection)			BCM -Body Control Module			*	*	*	
AUSFORD	Australia	2011	Ranger 3.2L(Duratorq-Turbo Diesel Common Rail Injection)			IPC -INSTRUMENT PANEL CONTROL MODULE			*	*	*	

Mark X Description Function is supported.

AUSFORD	Australia	2011	Ranger 3.2L(Duratorq-Turbo Diesel Common Rail Injection)			PAM -PARK AID MODULE			*	*	*	
AUSFORD	Australia	2011	Ranger 3.2L(Duratorq-Turbo Diesel Common Rail Injection)			ACM -AUDIO CONTROL MODULE			*	*	*	
AUSFORD	Australia	2011	Ranger 3.2L(Duratorq-Turbo Diesel Common Rail Injection)			DDM -Driver's Door Module			*	*	*	
AUSFORD	Australia	2011	Ranger 3.2L(Duratorq-Turbo Diesel Common Rail Injection)			FCDIM -Front Control/Dispaly Interface Module			*	*	*	
AUSFORD	Australia	2011	Ranger 3.2L(Duratorq-Turbo Diesel Common Rail Injection)			HVAC -Heating Ventilation Air Conditioning			*	*	*	
AUSFORD	Australia	2011	Ranger 3.2L(Duratorq-Turbo Diesel Common Rail Injection)			PDM -Passenger's Door Module			*	*	*	
AUSFORD	Australia	2011	Ranger 3.2L(Duratorq-Turbo Diesel Common Rail Injection)			SRM -Speech Recognition Module			*	*	*	
AUSFORD	Australia	2011	Ranger 3.2L(Duratorq-Turbo Diesel Common Rail Injection)			TRM -Trailer Module			*	*	*	
AUSFORD	Australia	2011	Ranger 2.2L(Duratorq-Turbo Diesel Common Rail Injection)			PCM -POWERTRAIN CONTROL MODULE			*	*	*	
AUSFORD	Australia	2011	Ranger 2.2L(Duratorq-Turbo Diesel Common Rail Injection)			ABS -ANTILOCK BRAKE MODULE			*	*	*	
AUSFORD	Australia	2011	Ranger 2.2L(Duratorq-Turbo Diesel Common Rail Injection)			RCM -RESTRAINT CONTROL MODULE			*	*	*	
AUSFORD	Australia	2011	Ranger 2.2L(Duratorq-Turbo Diesel Common Rail Injection)			TCM -TRANS CONTROL MODULE			*	*	*	
AUSFORD	Australia	2011	Ranger 2.2L(Duratorq-Turbo Diesel			BCM -Body Control Module			*	*	*	

Mark
X Description
Function is supported.

Mark	Description	Function is supported.										
			Common Rail Injection)									
AUSFORD	Australia	2011	Ranger 2.2L(Duratorq-Turbo Diesel Common Rail Injection)			IPC -INSTRUMENT PANEL CONTROL MODULE			*	*	*	
AUSFORD	Australia	2011	Ranger 2.2L(Duratorq-Turbo Diesel Common Rail Injection)			PAM -PARK AID MODULE			*	*	*	
AUSFORD	Australia	2011	Ranger 2.2L(Duratorq-Turbo Diesel Common Rail Injection)			ACM -AUDIO CONTROL MODULE			*	*	*	
AUSFORD	Australia	2011	Ranger 2.2L(Duratorq-Turbo Diesel Common Rail Injection)			DDM -Driver's Door Module			*	*	*	
AUSFORD	Australia	2011	Ranger 2.2L(Duratorq-Turbo Diesel Common Rail Injection)			FCDIM -Front Control/Dispaly Interface Module			*	*	*	
AUSFORD	Australia	2011	Ranger 2.2L(Duratorq-Turbo Diesel Common Rail Injection)			HVAC -Heating Ventilation Air Conditioning			*	*	*	
AUSFORD	Australia	2011	Ranger 2.2L(Duratorq-Turbo Diesel Common Rail Injection)			PDM -Passenger's Door Module			*	*	*	
AUSFORD	Australia	2011	Ranger 2.2L(Duratorq-Turbo Diesel Common Rail Injection)			SRM -Speech Recognition Module			*	*	*	
AUSFORD	Australia	2011	Ranger 2.2L(Duratorq-Turbo Diesel Common Rail Injection)			TRM -Trailer Module			*	*	*	
AUSFORD	Australia	2011	Ranger 4.0L			PCM -POWERTRAIN CONTROL MODULE			X	X	X	
AUSFORD	Australia	2011	Ranger 4.0L			RCM -RESTRAINT CONTROL MODULE			X	X	X	
AUSFORD	Australia	2011	Ranger 4.0L			ABS -ANTILOCK BRAKE MODULE			X	X	X	X
AUSFORD	Australia	2011	Ranger 4.0L			GEM -GENERIC ELECTRIC MODULE(OR CTM)			X	X	X	X

Mark
X Description
Function is supported.

AUSFORD	Australia	2011	Ranger 4.0L			ICM -INSTRUMENT CLUSTER MODULE			X	X	X	X
AUSFORD	Australia	2011	Ranger 4.0L			4X4 -4X4 Control Module			X	X	X	
AUSFORD	Australia	2011	Ranger 4.0L			OCSM -Occupant Classification System Module			X	X	X	
AUSFORD	Australia	2011	Ranger 4.0L			SDARS -Satellite Digital Audio Receiver System			X	X	X	
AUSFORD	Australia	2011	Territory 2.7L			PCM -POWERTRAIN CONTROL MODULE			X	X	X	
AUSFORD	Australia	2011	Territory 2.7L			RCM -RESTRAINT CONTROL MODULE			X	X	X	
AUSFORD	Australia	2011	Territory 2.7L			TCM -TRANS CONTROL MODULE			X	X	X	
AUSFORD	Australia	2011	Territory 2.7L			ABS -ANTILOCK BRAKE MODULE			X	X	X	X
AUSFORD	Australia	2011	Territory 2.7L			ACM -AUDIO CONTROL MODULE			X	X	X	
AUSFORD	Australia	2011	Territory 2.7L			BEM -BODY ELECTRIC MODULE			X	X	X	X
AUSFORD	Australia	2011	Territory 2.7L			FDIM -FRONT DISPLAY INTERFACE MODULE			X	X	X	
AUSFORD	Australia	2011	Territory 2.7L			HIM -HVAC INITEGRAED MODULE			X	X	X	
AUSFORD	Australia	2011	Territory 2.7L			IPC -INSTRUMENT PANEL CONTROL MODULE			X	X	X	
AUSFORD	Australia	2011	Territory 2.7L			PAM -PARK AID MODULE			X	X	X	
AUSFORD	Australia	2011	Territory 2.7L			PSCM -Power Steering Control Module			X	X	X	
AUSFORD	Australia	2011	Territory 4.0L			PCM -POWERTRAIN CONTROL MODULE			X	X	X	
AUSFORD	Australia	2011	Territory 4.0L			RCM -RESTRAINT CONTROL MODULE			X	X	X	
AUSFORD	Australia	2011	Territory 4.0L			TCM -TRANS CONTROL MODULE			X	X	X	

Mark X Description Function is supported.

AUSFORD	Australia	2011	Territory 4.0L			ABS -ANTILOCK BRAKE MODULE			X	X	X	
AUSFORD	Australia	2011	Territory 4.0L			ACM -AUDIO CONTROL MODULE			X	X	X	
AUSFORD	Australia	2011	Territory 4.0L			BEM -BODY ELECTRIC MODULE			X	X	X	
AUSFORD	Australia	2011	Territory 4.0L			FDIM -FRONT DISPLAY INTERFACE MODULE			X	X	X	
AUSFORD	Australia	2011	Territory 4.0L			HIM -HVAC INITEGRAED MODULE			X	X	X	
AUSFORD	Australia	2011	Territory 4.0L			IPC -INSTRUMENT PANEL CONTROL MODULE			X	X	X	
AUSFORD	Australia	2011	Territory 4.0L			PAM -PARK AID MODULE			X	X	X	
AUSFORD	Australia	2011	Territory 4.0L			PCM -POWERTRAIN CONTROL MODULE			X	X	X	
AUSFORD	Australia	2011	Territory 4.0L			RCM -RESTRAINT CONTROL MODULE			X	X	X	
AUSFORD	Australia	2011	Territory 4.0L			TCM -TRANS CONTROL MODULE			X	X	X	
AUSFORD	Australia	2010	Falcon Forte S/Futura/XR/XT 4.0L			ABS -ANTILOCK BRAKE MODULE			X	X	X	
AUSFORD	Australia	2010	Falcon Forte S/Futura/XR/XT 4.0L			BEM -BODY ELECTRIC MODULE			X	X	X	
AUSFORD	Australia	2010	Falcon Forte S/Futura/XR/XT 4.0L			IABM -INTG AIR BAG MONITOR			X	X	X	
AUSFORD	Australia	2010	Falcon Forte S/Futura/XR/XT 4.0L			ICM -INSTRUMENT CLUSTER MODULE			X	X	X	
AUSFORD	Australia	2010	Falcon Forte S/Futura/XR/XT 4.0L			PCM -POWERTRAIN CONTROL MODULE			X	X	X	
AUSFORD	Australia	2010	Falcon Forte S/Futura/XR/XT 4.0L			PAM -PARK AID MODULE			X	X	X	X
AUSFORD	Australia	2004	FALCON XT 4.0L BA			PAM -PARK AID MODULE			X	X	X	X
AUSFORD	Australia	2004	FALCON XR6 4.0L BA			PAM -PARK AID MODULE			X	X	X	X

Mark
X Description
Function is supported.

AUSFORD	Australia	2004	FALCON XR8 5.0L BA			PAM -PARK AID MODULE			X	X	X	X
AUSFORD	Australia	2002	FAIRLANE/LTD 4.0L AUIII			ICM -INSTRUMENT CLUSTER MODULE			X	X	X	X
AUSFORD	Australia	2002	FAIRLANE/LTD 5.0L AUIII			ICM -INSTRUMENT CLUSTER MODULE			X	X	X	X
AUSFORD	Australia	2002	FAIRMONT 4.0L AUIII			ICM -INSTRUMENT CLUSTER MODULE			X	X	X	X
AUSFORD	Australia	2002	FAIRMONT 5.0L AUIII			ICM -INSTRUMENT CLUSTER MODULE			X	X	X	X
AUSFORD	Australia	2002	FALCON FORTE 4.0L AUIII			ICM -INSTRUMENT CLUSTER MODULE			X	X	X	X
AUSFORD	Australia	2002	FALCON FUTURA 4.0L AUIII			ICM -INSTRUMENT CLUSTER MODULE			X	X	X	X
AUSFORD	Australia	2002	FALCON XR 4.0L AUIII			ICM -INSTRUMENT CLUSTER MODULE			X	X	X	X
AUSFORD	Australia	2002	FALCON XR 5.0L AUIII			ICM -INSTRUMENT CLUSTER MODULE			X	X	X	X
AUSFORD	Australia	2002	TRANSIT 2.5L DIESEL			PCM -POWERTRAIN CONTROL MODULE			X	X	X	
AUSFORD	Australia	2001	FAIRLANE/LTD 4.0L AUII			ICM -INSTRUMENT CLUSTER MODULE			X	X	X	X
AUSFORD	Australia	2001	FAIRLANE/LTD 5.0L AUII			ICM -INSTRUMENT CLUSTER MODULE			X	X	X	X
AUSFORD	Australia	2001	FAIRMONT 4.0L AUII			ICM -INSTRUMENT CLUSTER MODULE			X	X	X	X
AUSFORD	Australia	2001	FAIRMONT 5.0L AUII			ICM -INSTRUMENT CLUSTER MODULE			X	X	X	X
AUSFORD	Australia	2001	FALCON FORTE 4.0L AUII			ICM -INSTRUMENT CLUSTER MODULE			X	X	X	X
AUSFORD	Australia	2001	FALCON FUTURA 4.0L AUII			ICM -INSTRUMENT CLUSTER MODULE			X	X	X	X
AUSFORD	Australia	2001	FALCON XR 4.0L AUII			ICM -INSTRUMENT CLUSTER MODULE			X	X	X	X
AUSFORD	Australia	2001	FALCON XR 5.0L AUII			ICM -INSTRUMENT CLUSTER MODULE			X	X	X	X

Mark
X Description
Function is supported.

AUSFORD	Australia	2001	TRANSIT 2.5L DIESEL			PCM -POWERTRAIN CONTROL MODULE			X	X	X	
AUSFORD	Australia	2000	COUGAR 2.5L			PCM -POWERTRAIN CONTROL MODULE			X	X	X	
AUSFORD	Australia	2000	ESCORT 1.8L			PCM -POWERTRAIN CONTROL MODULE			X	X	X	
AUSFORD	Australia	2000	ESCORT 1.8L			PATS -PASSIVE ANTITHEFT MODULE			X	X	X	X
AUSFORD	Australia	2000	ESCORT 1.8L DIESEL			PCM -POWERTRAIN CONTROL MODULE			X	X	X	
AUSFORD	Australia	2000	ESCORT 1.8L DIESEL			PATS -PASSIVE ANTITHEFT MODULE			X	X	X	X
AUSFORD	Australia	2000	ESCORT 1.8L DIESEL			RIM -REMOTE IMMOBILIZER MODULE			X	X		
AUSFORD	Australia	2000	EXPLORER 4.0L			PCM -POWERTRAIN CONTROL MODULE			X	X	X	
AUSFORD	Australia	2000	EXPLORER 4.0L			PATS -PASSIVE ANTITHEFT MODULE			X	X	X	X
AUSFORD	Australia	2000	FAIRLANE/LTD 4.0L AUII			ICM -INSTRUMENT CLUSTER MODULE			X	X	X	X
AUSFORD	Australia	2000	FAIRLANE/LTD 5.0L AUII			ICM -INSTRUMENT CLUSTER MODULE			X	X	X	X
AUSFORD	Australia	2000	FAIRMONT 4.0L AUII			ICM -INSTRUMENT CLUSTER MODULE			X	X	X	X
AUSFORD	Australia	2000	FAIRMONT 5.0L AUII			ICM -INSTRUMENT CLUSTER MODULE			X	X	X	X
AUSFORD	Australia	2000	FALCON FORTE 4.0L AUII			ICM -INSTRUMENT CLUSTER MODULE			X	X	X	X
AUSFORD	Australia	2000	FALCON FUTURA 4.0L AUII			ICM -INSTRUMENT CLUSTER MODULE			X	X	X	X
AUSFORD	Australia	2000	FALCON XR 4.0L AUII			ICM -INSTRUMENT CLUSTER MODULE			X	X	X	X
AUSFORD	Australia	2000	FALCON XR 5.0L AUII			ICM -INSTRUMENT CLUSTER MODULE			X	X	X	X
AUSFORD	Australia	2000	KA 1.3L			PCM -POWERTRAIN CONTROL MODULE			X	X	X	

Mark
X Description
Function is supported.

AUSFORD	Australia	2000	MONDEO 1.8L HC			PCM -POWERTRAIN CONTROL MODULE			X	X	X	
AUSFORD	Australia	2000	MONDEO 1.8L DIESEL			PCM -POWERTRAIN CONTROL MODULE			X	X	X	
AUSFORD	Australia	2000	MONDEO 1.8L DIESEL			PATS -PASSIVE ANTITHEFT MODULE			X	X	X	X
AUSFORD	Australia	2000	MONDEO 1.8L DIESEL			RIM -REMOTE IMMOBILIZER MODULE			X	X		
AUSFORD	Australia	2000	MONDEO 2.0L HC			PCM -POWERTRAIN CONTROL MODULE			X	X	X	
AUSFORD	Australia	2000	MONDEO 2.5L HC			PCM -POWERTRAIN CONTROL MODULE			X	X	X	
AUSFORD	Australia	2000	MUSTANG 4.6L			PCM -POWERTRAIN CONTROL MODULE			X	X	X	
AUSFORD	Australia	2000	MUSTANG 4.6L 2V/4V			PCM -POWERTRAIN CONTROL MODULE			X	X	X	
AUSFORD	Australia	2000	TRANSIT 2.0L			PCM -POWERTRAIN CONTROL MODULE			X	X	X	
AUSFORD	Australia	2000	TRANSIT 2.0L			PATS -PASSIVE ANTITHEFT MODULE			X	X	X	X
AUSFORD	Australia	2000	TRANSIT 2.5L DIESEL			PCM -POWERTRAIN CONTROL MODULE			X	X	X	
AUSFORD	Australia	2000	TRANSIT 2.5L DIESEL			PATS -PASSIVE ANTITHEFT MODULE			X	X	X	X
AUSFORD	Australia	1999	COUGAR 2.0L			PCM -POWERTRAIN CONTROL MODULE			X	X	X	
AUSFORD	Australia	1999	COUGAR 2.5L			PCM -POWERTRAIN CONTROL MODULE			X	X	X	
AUSFORD	Australia	1999	ESCORT 1.8L			PCM -POWERTRAIN CONTROL MODULE			X	X	X	
AUSFORD	Australia	1999	ESCORT 1.8L			PATS -PASSIVE ANTITHEFT MODULE			X	X	X	X
AUSFORD	Australia	1999	ESCORT 1.8 DIESEL			PCM -POWERTRAIN CONTROL MODULE			X	X	X	
AUSFORD	Australia	1999	ESCORT 1.8 DIESEL			PATS -PASSIVE ANTITHEFT MODULE			X	X	X	X

Mark
X Description
Function is supported.

AUSFORD	Australia	1999	ESCORT 1.8 DIESEL			RIM -REMOTE IMMOBILIZER MODULE			X	X		
AUSFORD	Australia	1999	EXPLORER 4.0L			PCM -POWERTRAIN CONTROL MODULE			X	X	X	
AUSFORD	Australia	1999	EXPLORER 4.0L			PATS -PASSIVE ANTITHEFT MODULE			X	X	X	X
AUSFORD	Australia	1999	FAIRLANE/LTD 4.0L AU			BEM -BODY ELECTRIC MODULE				X	X	X
AUSFORD	Australia	1999	FAIRLANE/LTD 4.0L AU			ICM -INSTRUMENT CLUSTER MODULE					X	X
AUSFORD	Australia	1999	FAIRLANE/LTD 5.0L AU			BEM -BODY ELECTRIC MODULE				X	X	X
AUSFORD	Australia	1999	FAIRLANE/LTD 5.0L AU			ICM -INSTRUMENT CLUSTER MODULE					X	X
AUSFORD	Australia	1999	FAIRMONT 4.0L AU			BEM -BODY ELECTRIC MODULE				X	X	X
AUSFORD	Australia	1999	FAIRMONT 4.0L AU			ICM -INSTRUMENT CLUSTER MODULE					X	X
AUSFORD	Australia	1999	FAIRMONT 5.0L AU			BEM -BODY ELECTRIC MODULE				X	X	X
AUSFORD	Australia	1999	FAIRMONT 5.0L AU			ICM -INSTRUMENT CLUSTER MODULE					X	X
AUSFORD	Australia	1999	FALCON FUTRA 4.0L AU			BEM -BODY ELECTRIC MODULE				X	X	X
AUSFORD	Australia	1999	FALCON FUTRA 4.0L AU			ICM -INSTRUMENT CLUSTER MODULE					X	X
AUSFORD	Australia	1999	FALCON FUTRA 5.0L AU			BEM -BODY ELECTRIC MODULE				X	X	X
AUSFORD	Australia	1999	FALCON FUTRA 5.0L AU			ICM -INSTRUMENT CLUSTER MODULE					X	X
AUSFORD	Australia	1999	FALCON FORTE 4.0L AU			BEM -BODY ELECTRIC MODULE				X	X	X
AUSFORD	Australia	1999	FALCON FORTE 4.0L AU			ICM -INSTRUMENT CLUSTER MODULE					X	X
AUSFORD	Australia	1999	FALCON FORTE 5.0L AU			BEM -BODY ELECTRIC MODULE				X	X	X

Mark
X Description
Function is supported.

AUSFORD	Australia	1999	FALCON FORTE 5.0L AU			ICM -INSTRUMENT CLUSTER MODULE					X	X
AUSFORD	Australia	1999	KA 1.3L			PCM -POWERTRAIN CONTROL MODULE			X	X	X	
AUSFORD	Australia	1999	MONDEO 1.8L HC			PCM -POWERTRAIN CONTROL MODULE			X	X	X	
AUSFORD	Australia	1999	MONDEO 1.8L DIESEL			PCM -POWERTRAIN CONTROL MODULE			X	X	X	
AUSFORD	Australia	1999	MONDEO 1.8L DIESEL			PATS -PASSIVE ANTITHEFT MODULE			X	X	X	X
AUSFORD	Australia	1999	MONDEO 1.8L DIESEL			RIM -REMOTE IMMOBILIZER MODULE			X	X		
AUSFORD	Australia	1999	MONDEO 2.0L HC HTX			PCM -POWERTRAIN CONTROL MODULE			X	X	X	
AUSFORD	Australia	1999	MONDEO 2.0L HC MTX			PCM -POWERTRAIN CONTROL MODULE			X	X	X	
AUSFORD	Australia	1999	MONDEO 2.5L HC			PCM -POWERTRAIN CONTROL MODULE			X	X	X	
AUSFORD	Australia	1999	TRANSIT 2.0L			PCM -POWERTRAIN CONTROL MODULE			X	X	X	
AUSFORD	Australia	1999	TRANSIT 2.0L			PATS -PASSIVE ANTITHEFT MODULE			X	X	X	X
AUSFORD	Australia	1999	TRANSIT 2.5L DIESEL			PCM -POWERTRAIN CONTROL MODULE			X	X	X	
AUSFORD	Australia	1999	TRANSIT 2.5L DIESEL			PATS -PASSIVE ANTITHEFT MODULE			X	X	X	X
AUSFORD	Australia	1998	ESCORT 1.6L ATX			PCM -POWERTRAIN CONTROL MODULE			X	X	X	
AUSFORD	Australia	1998	ESCORT 1.6L ATX			PATS -PASSIVE ANTITHEFT MODULE			X	X	X	X
AUSFORD	Australia	1998	ESCORT 1.8L			PCM -POWERTRAIN CONTROL MODULE			X	X	X	
AUSFORD	Australia	1998	ESCORT 1.8L			PATS -PASSIVE ANTITHEFT MODULE			X	X	X	X
AUSFORD	Australia	1998	ESCORT 1.8L DIESEL			PCM -POWERTRAIN CONTROL MODULE			X	X	X	

Mark
X Description
Function is supported.

AUSFORD	Australia	1998	ESCORT 1.8L DIESEL			PATS -PASSIVE ANTITHEFT MODULE			X	X	X	X
AUSFORD	Australia	1998	ESCORT 1.8L DIESEL			RIM -REMOTE IMMOBILIZER MODULE			X	X		
AUSFORD	Australia	1998	EXPLORER 4.0L			PCM -POWERTRAIN CONTROL MODULE			X	X	X	
AUSFORD	Australia	1998	MONDEO 1.8L HC			PCM -POWERTRAIN CONTROL MODULE			X	X	X	
AUSFORD	Australia	1998	MONDEO 1.8L HC			PATS -PASSIVE ANTITHEFT MODULE			X	X	X	X
AUSFORD	Australia	1998	MONDEO 1.8L DIESEL			PCM -POWERTRAIN CONTROL MODULE			X	X	X	
AUSFORD	Australia	1998	MONDEO 1.8L DIESEL			PATS -PASSIVE ANTITHEFT MODULE			X	X	X	X
AUSFORD	Australia	1998	MONDEO 1.8L DIESEL			RIM -REMOTE IMMOBILIZER MODULE			X	X		
AUSFORD	Australia	1998	MONDEO 2.0L HC ATX			PCM -POWERTRAIN CONTROL MODULE			X	X	X	
AUSFORD	Australia	1998	MONDEO 2.0L HC ATX			PATS -PASSIVE ANTITHEFT MODULE			X	X	X	X
AUSFORD	Australia	1998	MONDEO 2.0L HC MTX			PCM -POWERTRAIN CONTROL MODULE			X	X	X	
AUSFORD	Australia	1998	MONDEO 2.0L HC MTX			PATS -PASSIVE ANTITHEFT MODULE			X	X	X	X
AUSFORD	Australia	1998	MONDEO 2.5L HC			PCM -POWERTRAIN CONTROL MODULE			X	X	X	
AUSFORD	Australia	1998	MONDEO 2.5L HC			PATS -PASSIVE ANTITHEFT MODULE			X	X	X	X
AUSFORD	Australia	1998	TAURUS 3.0L 4V			PCM -POWERTRAIN CONTROL MODULE			X	X	X	
AUSFORD	Australia	1998	TRANSIT 2.0L			PCM -POWERTRAIN CONTROL MODULE			X	X	X	
AUSFORD	Australia	1998	TRANSIT 2.0L			PATS -PASSIVE ANTITHEFT MODULE			X	X	X	X
AUSFORD	Australia	1998	TRANSIT 2.5L DIESEL			PCM -POWERTRAIN CONTROL MODULE			X	X	X	

Mark
X Description
Function is supported.

AUSFORD	Australia	1998	TRANSIT 2.5L DIESEL			PATS -PASSIVE ANTITHEFT MODULE			X	X	X	X
AUSFORD	Australia	1998	TRANSIT 2.5L DIESEL			RIM -REMOTE IMMOBILIZER MODULE			X	X		
AUSFORD	Australia	1997	ESCORT 1.4L			PATS -PASSIVE ANTITHEFT MODULE			X	X	X	X
AUSFORD	Australia	1997	ESCORT 1.6L MTX			PATS -PASSIVE ANTITHEFT MODULE			X	X	X	X
AUSFORD	Australia	1997	ESCORT 1.8L			PCM -POWERTRAIN CONTROL MODULE			X	X	X	
AUSFORD	Australia	1997	ESCORT 1.8L			PATS -PASSIVE ANTITHEFT MODULE			X	X	X	X
AUSFORD	Australia	1997	ESCORT 1.8L DIESEL			PCM -POWERTRAIN CONTROL MODULE			X	X	X	
AUSFORD	Australia	1997	ESCORT 1.8L DIESEL			PATS -PASSIVE ANTITHEFT MODULE			X	X	X	X
AUSFORD	Australia	1997	EXPLORER 4.0L ATX			PCM -POWERTRAIN CONTROL MODULE			X	X	X	
AUSFORD	Australia	1997	EXPLORER 4.0L ATX			ABS -ANTILOCK BRAKE MODULE			X	X	X	X
AUSFORD	Australia	1997	EXPLORER 4.0L MTX			PCM -POWERTRAIN CONTROL MODULE			X	X	X	
AUSFORD	Australia	1997	EXPLORER 4.0L MTX			ABS -ANTILOCK BRAKE MODULE			X	X	X	X
AUSFORD	Australia	1997	MONDEO 1.8L HC			PCM -POWERTRAIN CONTROL MODULE			X	X	X	
AUSFORD	Australia	1997	MONDEO 1.8L HC			ABS -ANTILOCK BRAKE MODULE			X	X	X	
AUSFORD	Australia	1997	MONDEO 1.8L HC			PATS -PASSIVE ANTITHEFT MODULE			X	X	X	X
AUSFORD	Australia	1997	MONDEO 1.8L DIESEL			PCM -POWERTRAIN CONTROL MODULE			X	X	X	
AUSFORD	Australia	1997	MONDEO 1.8L DIESEL			ABS -ANTILOCK BRAKE MODULE			X	X	X	
AUSFORD	Australia	1997	MONDEO 1.8L DIESEL			PATS -PASSIVE ANTITHEFT MODULE			X	X	X	X

Mark
X Description
Function is supported.

AUSFORD	Australia	1997	MONDEO 1.8L DIESEL			RIM -REMOTE IMMOBILIZER MODULE			X	X		
AUSFORD	Australia	1997	MONDEO 2.0L HC ATX			PCM -POWERTRAIN CONTROL MODULE			X	X	X	
AUSFORD	Australia	1997	MONDEO 2.0L HC ATX			ABS -ANTILOCK BRAKE MODULE			X	X	X	
AUSFORD	Australia	1997	MONDEO 2.0L HC ATX			PATS -PASSIVE ANTITHEFT MODULE			X	X	X	X
AUSFORD	Australia	1997	MONDEO 2.0L HC MTX			PCM -POWERTRAIN CONTROL MODULE			X	X	X	
AUSFORD	Australia	1997	MONDEO 2.0L HC MTX			ABS -ANTILOCK BRAKE MODULE			X	X	X	
AUSFORD	Australia	1997	MONDEO 2.0L HC MTX			PATS -PASSIVE ANTITHEFT MODULE			X	X	X	X
AUSFORD	Australia	1997	MONDEO 2.5L HC			PCM -POWERTRAIN CONTROL MODULE			X	X	X	
AUSFORD	Australia	1997	MONDEO 2.5L HC			ABS -ANTILOCK BRAKE MODULE			X	X	X	
AUSFORD	Australia	1997	MONDEO 2.5L HC			PATS -PASSIVE ANTITHEFT MODULE			X	X	X	X
AUSFORD	Australia	1997	TAURUS 3.0L 4V			PCM -POWERTRAIN CONTROL MODULE			X	X	X	
AUSFORD	Australia	1997	TRANSIT 2.0L			PCM -POWERTRAIN CONTROL MODULE			X	X	X	
AUSFORD	Australia	1997	TRANSIT 2.0L			PATS -PASSIVE ANTITHEFT MODULE			X	X	X	X
AUSFORD	Australia	1997	TRANSIT 2.5L DIESEL			PCM -POWERTRAIN CONTROL MODULE			X	X	X	
AUSFORD	Australia	1997	TRANSIT 2.5L DIESEL			PATS -PASSIVE ANTITHEFT MODULE			X	X	X	X
AUSFORD	Australia	1997	TRANSIT 2.5L DIESEL			RIM -REMOTE IMMOBILIZER MODULE			X	X		
AUSFORD	Australia	1996	TAURUS 3.0L 4V			PCM -POWERTRAIN CONTROL MODULE			X	X	X	
AUSFORD	Australia	1996	TRANSIT 2.0L			PCM -POWERTRAIN CONTROL MODULE			X	X	X	

Mark
X Description
Function is supported.

Mark	Description		Function is supported.									
AUSFORD	Australia	1996	TRANSIT 2.0L			PATS -PASSIVE ANTITHEFT MODULE			X	X	X	X
AUSFORD	Australia	1996	TRANSIT 2.5L DIESEL			PCM -POWERTRAIN CONTROL MODULE			X	X	X	
AUSFORD	Australia	1996	TRANSIT 2.5L DIESEL			PATS -PASSIVE ANTITHEFT MODULE			X	X	X	X